



SALTO

inspired **access**

www.saltosystems.com

Pro-Access READ/ WRITE ACCESS CONTROL

User Manual V 10.5.00.x

1. INTRODUCTION:	6
2. PROGRAM INSTALLATION	8
MDAC	8
MDAC Installation on your system	8
SQL MS Server	9
3. SALTO SERVICE RW	24
4. SOFTWARE OPERATORS AND COMPETENCIES	30
Creating a new DB	30
Migrating an existing MS-Access DB to a MS-SQLServer DB	32
Operator competencies	33
5. IMPORT TOOL	40
Data type	40
Text file	40
Excel file	42
Importing User List, Door List, Zone List and Access level List:	42
6. EXPORT:	47
7. ADMINISTRATOR OPERATOR	50
Doors.	51
Zones.	66
Outputs	71
Automatic Outputs:	73
Time periods.	74
Time zones.	77
Calendars.	79
Time change.	82

Automatic changes	85
Users access levels	88
Users.	96
User key assignment	107
I-Locker.	112
Free Assignment Zone:	112
Define iLockers:	112
Define Free Assignment Zones:	114
Free Closing:	114
Types of Keys:	115
Time-limited Occupancy:	115
i-Locker & Visitors:	116
ILocker Initialisation:	116
Visits:	118
Vistors Checkin :	119
Checkout visitors:	120
Blacklist	121
Blacklist Configuration	121
Automatic key up date	123
Using PPD. Initialization	124
Main menu:	125
Initializing doors:	125
8. ADVANCED OPTIONS	129
General info	129
PPD status	130
Encoder status	133
Configuration of Ethernet encoders	134
Lock status.	135
Advanced parameters	137
Automatic Purge	138
User	140
Writing extra info on track 1, 2 or 3 for staff keys	141

Writing extra info in users cards:	142
Show Key detect mode:	145
Show ROM code:	146
Wiegand Code:	147
Port ranges	150
Auto Logoff	151
Automatic Purged	152
Automatic Key Assignment	154
More useful tools.	156
Key issuing	156
Auditor	161
On line	162
Peripheral menu	163
Monitoring On Line Control Units	163
Multiple Online Monitoring (only for Service)	169
Peripheral List	171
Peripheral Initialization	174
Inhibit Master communication	175
Encoder and PPD firmware update	177
Update the readers:	178
Roll-Call:	179
How to create a Roll-Call area:	179
Extra Area:	180
Example:	180
Monitoring of Roll-Call areas	181
Limited occupancy	182
Language. Language change.	184
Log-out. Change operator.	184
PPD connection. Portable programmer.	185
Audit Trail. Collecting door opening data.	187
New filter	190
Create a new filter	190
Save the filter:	195
Card Template List (only for Service).	195

9. DEPARTMENT DATA BASE CONFIGURATION	201
Activate departments feature	201
How to create departments	202
Internal elements	203
Share elements	205
Users automatically shared	206
External elements	207
Operations	208
Operator Groups	208
How to work with external elements	210
Audit trail	214
Programming and spare keys	214
10. AUTOMATIC USER DATA SYNCHRONISATION TOOL	216
11. SALTO HOST INTERFACE PROTOCOL SHIP	221
Activate communication SALTO (server) – Host (client)	222
Activate communication SALTO (client) – Host (Server)	222
12. SALTO WIRELESS	224
SYSTEM SETUP	224
LOCKDOWN	233

1. Introduction:

SALTO RW Pro-Access software has been developed to manage access control to buildings where *read-write* ID elements are used (smart cards).

Using this system two main tasks can be accomplished:

- Design the locking schedule and perform the first electronic lock initialisation.
- Support an application usable by software operators to edit the user's key cards.

The ability of managing On line wall readers and updaters is a feature only available in the **PA Connected** or higher software. These functions are not supplied with the standard PA software.




Figure 1.

Once the locking schedule has been designed, we can transfer it to every door within our facilities by PPD, a small portable programming device, which will be essential to implement the installation, and to audit doors whenever you want.

To sum up, you will need the following elements in order to manage hotel access control:

1. Salto PA Software installed in 1 PC .
2. RW iD elements, both for hotel personnel and guests. (keys).
3. RW escutcheons for those doors with access control procedures.
4. 1 card editor. ECX000.
5. 1 portable programmer (PPDX00).

2. Program installation

To install the software provided by SALTO, your minimum system requirement should comply with the following:

Under an SQL DB

RAM; 1GB.

Processor; 1 GHz or higher. 32Bits and 64Bits.

Hard disk available space; 10 GB. (Aprox. depends on the DB)

Operating system; Windows 2000, NT 4.0, XP, Vista, Windows 7.

MS-SQL Express, MS-SQL 2000, MS-SQL 2005 or 2008

The CD-ROM provided by SALTO contains a wizard for easy installation that runs automatically, when you double click the "SETUP .EXE" icon. Follow the wizard instructions for installation.

WARNING: make sure that your PC clock has the right time, and that it set correctly, since the SALTO system time will be based on your PC clock.

Salto software allows you to work with a multiworkstation configuration, that is to say, the program can be used on different PCs simultaneously, with the same data base. The main condition being that every user is provided access with read/write privileges to the SALTO DB within the SQLServer.

MDAC

Salto RW application requires MDAC (Microsoft Data Access Components) 2.1 version or higher installed on the system. This requirement is met by the latest operating systems such as Windows 2000 or Millennium, where MDAC 2.5 is a default installed option.

MDAC Installation on your system

SALTO installation program contains also the executable file "mdac_typ.exe", that runs MDAC 2.5 version. Before proceeding to install this, perform the following steps:


- Check that your system has no MDAC or a lower version than 2.1 already installed (see previous paragraph).
- Close all currently active applications, above all those that could use MDAC such as: Word, Excel, Access, Power Point, Internet Explorer, Outlook, etc...
- With Windows NT, as a precautionary measure, log in as a user with administrator privileges.
- Double click the executable file "mdac_typ.exe" contained in the CD-ROM provided by SALTO in order to install in your hard disk 2.5 version. To localise this file, select the path: D:\Mdac\ Mdac2.5SP2\ Language\ mdac_typ.
- It is advisable to read the mdac_readme file, to obtain more information.

SQL MS Server


To work with this application it is needed to have installed on the computer the MS SQL Server 2000, 2005 or 2008. Even it is recommended to have installed the Microsoft SQL Server management Studio as well.

The Salto software is available to work on the windows authentication and SQL authentication. This Software is available in the following site:


<http://www.microsoft.com/downloads/details.aspx?displaylang=en&FamilyID=220549b5-0b07-4448-8848-dcc397514b41>



Accept terms and conditions and click next.




Installing Prerequisites, click Install



Prerequisites are installed, click next.




Click next.



Once the checking will be done, click next.

In case of errors, they will have to be fixed before continuing with the installation. It is possible that the 'Microsoft .NET Framework 2.0 or superior' is missing. In this case, it will have to be installed before continuing with the installation.




Place the name and the company. The name must be written, the company is optional.

Unselect the “Hide advanced configuration options” mark and click next.



Select the path where the SQL Express and its components must be installed.

The following features must be installed; Data Files, Shared Tools, y Connectivity Components. In order to select them, click on the option to select and chose, ‘will be installed on local hard drive’






Provide the name of the instance to be installed.

If only one instance will be installed in this machine, it is possible to select "Default Instance". In this case, when opening the Salto DB it would be enough to place the PC's name without the instance.

If an instance name is specified, in order to connect to a DB, it will be necessary to place; '**Server_name\Instance_name**'



After all the PC's components have been updated, click next.



Make sure to select the “Start services at the end of setup” option, SQL Server and SQL Browser.



In this window, it is necessary to select the authentication mode that will be used to open the DB. If the company has a domain and all the users will connect to the DB using the windows login, select the Windows Authentication.

On the other hand, if there isn't any existing domain or if we want to connect to the DB using an SQL user, it will be necessary to select the Mixed Mode and place a password for the administrator (sa) user. The password will have to be secured;

The secured password cannot follow some conditions neither prohibited terms as follows;

- a. NULL condition nor blank
- b. "Password"

- c. "Admin"
 - d. "Administrator"
 - e. "sa"
 - f. "sysadmin"
2. The secured passwords cannot contain the following terms related to the PC:
- a. Name of the user used to log the actual session.
 - b. Name of the PC.
3. A secured password must be at least 6 characters long and comply with at least 3 of the 4 criteria.
- a. Must contain uppercases.
 - b. Must contain lowercases letters.
 - c. Must contain numbers.
 - d. Must contain alphanumeric characters as i.e., #, % or ^.

If the authentication mode to use is not known, we recommend to use the mixed mode, as this mode allows both authentication modes.

If only the windows authentication mode has been selected and the SQL authentication mode is needed, it will be necessary to install the Management Studio software in order to modify this option.



Select the option Accent-sensitive. Other options must be unchecked. Click next.




Leave it as by default and click next.



Finally, click "Install" to start.


During installation, it may happen that the following error would appear when trying to install a 2005 or 2008 SQL server English version on a non English language Windows XP SP3 operative system.

To fix this error, it will be necessary to download SQL Server Express installer with the operative system language from Microsoft web site.



Remote conexions Service configurations


Now, we will use the "SQL Server Surface Area Configuration"



Now we go the "Servicies and conexions area configurations"




Select the “**Service**” for our SQL Server, (“**SQLEXPRESS**” as it is on the example) and make sure to set it as “**Automatic**”. Now, start the service.




On the “**Remote conexions**” check the following options:

- **Local and Remote Conexions**
- **Use TCP/IP and named pipes conexions**




Now, select **“Service”** from the **“SQL Server Browser”**, make sure that it is set as **“Automatic”** and start the service.



Opening the SQL DB

The next step is opening the DB.

Click **“File/ Open new DB”** and select the name of the server, the name of the service and below the name of the DB, (“SALTO_RW” by default) using the needed authentication mode.




SQL Server Configuration

This option represents an alternative to the SQL data base management software in order to create logins.

Logins will permit to have access to the database from different PCs so it is possible to have a shared installation between different computers.

Tools/Configuration/SQL Server Configuration menu gives access to the following screen:



This window manages the different logins to the SQL database. "Add new user" creates a new login with the following options:

- Login name
The format of this field depends on the authentication type (Windows or SQL)



Windows authentication uses existing network users. By default, the field will show the actual Windows domain so it can be completed with the user information.
i.e. SALTO\c.imesio

SQL authentication permits to create new names that are independent from the actual network configuration.
i.e. John




The password field is optional but may be used to improve the security level when connecting to the database.

This information will be used to connect to the database.

Caution!


It is important to choose correctly the SQL server. The list will display the different network servers. If SQL Express is used, the option xxx\SQLEXPRESS will be selected. Xxx stands for the name of the machine (i.e. Marketing05).



Add login to securityadmin server function

This function allows to the created users to create new logins.

SQL Services tab shows the different SQL servers installed. The services are displayed with the possibility to start them.



3. SALTO Service RW

SALTO RW Pro-Access for Service is based on a Windows Service called SALTO Service RW that manages the communications with the on-line peripherals: CUs, encoders (the wireless locks are not included on this release).

This service is intended to be the core application of the SALTO software managing the different modules: Pro-Access, PMS,...




Installation

The installation is launched from the *SetupSALTOService.msi* file and installs, together with the service itself, a little application dedicated to do the setup of the RW Pro-Access for its optimum performance.







After accepting the license agreement, an installation folder must be selected and the “Next” button will be enabled to start with the installation.



Once the process is finished, the “Close” button will end it and the service will be installed.



The Windows services list will now show it with the name **SALTO Service RW**.



Service Configurator

Although the service configuration can be done with the operating system tools, the Configurator brings some more specific options for its management.

The Service Configurator is composed of three general tabs:

- Database
- Service ports
- Service properties

Database

This tab contains information about the SQL database connection.

- Server name
The name or IP address of the machine containing the database must be detailed on this field (NOTE: when using the “Express” SQL server versions, “\SQLEXPRESS” will have to added after the name of the PC).
- Database
The database is target here.
- Serial No.
Software license number (not mandatory field).
- Server authentication
The authentication type can be selected between Windows or SQL (NOTE: The SQL authentication needs to have a valid SQL user created previously).




- **Test Connection**
It is possible to check the connection with the SQL data base.
- **Verify Db Version**
The SQL data base must be compatible with the service version.
Older data bases require to be updated from the Pro-Access itself in order to make them service compatible.
- **Create new database**
This option allows creating a new data base in order to be opened from the Pro-Access.

Service ports

The different ports are managed from this window.

The SALTO Service Location will open a socket to communicate with the different SALTO applications connected to it.

The bottom part is dedicated to open a port or a port range to communicate with the different peripherals.




Service properties

This screen is similar to the Windows one to manage the service properties. The Start Type can be defined (Automatic, Manual, Disabled). Start and Stop options are also available.

(*) LocalSystem option is recommended to start the Service.



The following icon  will indicate that the service is started and running (the same icon is shown under Pro-Access).

4. Software operators and competencies

Creating a new DB

RW program has two aspects, depending on the user name that begins the login session. (By default, the program has the user name: **ADMIN.** for the administrator)

The first time you login the program must be opened using the administrator login.

To open the program double click the shortcut icon on the desktop.

A window like Figure 1 with 2 fields will be displayed:

User name: type **admin..** in upper case.
Password: in your first login session is not necessary to choose one.

Validate both fields by clicking the "OK" box.




Figure.2

Since it is the first time that we have opened the program, Toolbar icons are disabled as "greyed out".

In order to activate the Toolbar, you need to name the data base that we will be using.

And assign a path and a directory in your computer.

- Click on the popup menu *FILE*.

- Select *NEW DB. option* (Figure 3.)
- A window like that of Figure 3 will display.




Figure 3

- To open or create a new data base through the PA RW SQL application Go to FILE/New Database. Then in the window write the name of the MS SQL Server program you want to work with. In the field below write the name of the data base you want to create
- You can write the software serial number in the matching field. this is a just informative purpose field..
- Validate data base name and SQL location (click "OK" button)
- Select the connect using: Windows or SQL authentication





Figure 4

Migrating an existing MS-Access DB to a MS-SQLServer DB

In some occasions the customer may not want to create a new SQL DB from scratch but instead start from an already existing MS-Access DB. In this regard, the SALTO application offers the possibility of migrating an existing MS-Access DB to a brand new MS-SQLServer DB.

To migrate an Access DB the admin has to go to File/New DB/Migration from MS Access, where the following screen will be showed:




Then clicking on the right bottom we can find where the MS-Access DB is located. Then we will name the new SQL DB and we have to specify which is the SQL server program we want to work with. When all this has been specified we can click on the start upgrade, if everything has been properly configured the migration will be successfully done.

Operator competencies

The administrator must specify program operators and their competencies. In other words, which options of the main menu operators will be allowed to use.

The administrator could also define its own and front desk operators' program access passwords.

Moreover, the super administrator can concede rights to other group operators in order to let them create operators for their own group. But those won't be able to do so.



Go to pop-up menu TOOLS/ OPERATORS AND PERMISSIONS/ OPERATORS, as is shown in the Figure.




Figure 5

By default, the system offers one operator, ADMINISTRATOR.



Figure 6

You will probably be required to create further operators.

To create a new operator, click the NEW button on the bottom part of the window. A blank window will be displayed, as shown in the following Figure:




Figure 7

- You will have to write the operator's name, his user name (that is stored at the login), and a password.
- The system brings, by default, 1 operator group: Administrator.
- Specify also the language this operator will use when running the application.

- Next, save changes and close the window.
- You must immediately inform the password you have just registered to the operator, since he will need it to access the application.

Follow this procedure as many times as new operator you want to create, and you will see how the operator list enlarges.



Figure 8

Once you have created the necessary new operators on your system, you may close this window and return to the TOOLS/ OPERATORS AND PERMISSIONS / OPERATORS GROUPS pull-up menu. Within this option operator competencies can be set.




Figure 9

Operators belonging to ADMINISTRATOR group may have access to full program menu functionality.

Administrator has the ability to create further operator groups, if he seems it convenient.

To create a new group, click the NEW button on the bottom part of this window.




Figure 10

In order to modify competencies of an existing group, you must highlight this group in the list (the line turns blue) and click the VIEW DETAILS button.

A window like that of the Figure 11 will be displayed.




Figure 11

- From this window, the operator may add or delete program functionality, by clicking with the mouse on the “check boxes” located on the left-hand side of every option. If the option is selected, this option will appear as an enabled option for the operator handling the program.

Were the option is left blank; it will not appear as an enabled option for the operator within this group.

- The administrator should save changes when all modifications have been completed.

5. Import tool

Data type

The importable information is as follows:

- User list: title, first name, last name, access level, general purpose field #1, #2 and #3.
- Door list: name and description.
- Zone list: name and description.
- Access level list: name and description.
- Access permissions between users and doors: user compound name and door name.
- Access permissions between users and zones: user compound name and zone name.
- Access permissions between access levels and doors: access level and door name.
- Access permissions between access levels and zones: access level and zone name.
- Relationships between doors and zones: door and zone name.

Note that the import process is not made on a transaction basis: this means that, if by any chance, errors occur in the middle of the process, the whole operation IS NOT rolled back or undone. Instead, errors are left aside and the import process continues until the end of file is reached.

Two file format are supported, namely, plain text (*.txt, *.csv, ...) and Excel file (*.xls).


Text file

The file must contain just plain text. Any document file containing extra formatting data (such as MS-Word *.doc, Rich Text File *.rtf, etc ...) are not supported.


Additionally, each of the characters in the text file must occupy just 1 byte (like in the ASCII character set): if a given file contains characters with 2 or more bytes long (like in the UNICODE character set), then data is not correctly imported.

Each row in the file corresponds to a row in the SALTO DB. Within a row, fields (or columns) must be separated by a character of your choice (normally, ';').

When importing, you must firstly specify the line at which data starts (zero-based) and the separator character. Afterwards, you must match each column in the text file with the corresponding SALTO field, as shown in the following picture:



(Fig.1)



(Fig. 2)


Excel file

All the data to be imported must be contained on one 'sheet'. It is strongly recommended for the excel file to include (within in the first positions) a row containing just text (for example, a header row containing titles for each column).

When importing data, the wizard asks you the name of the excel sheet at which data is located and the starting line (zero-based). As in the text format, you must also match each column in the excel sheet with the corresponding SALTO field.

Importing User List, Door List, Zone List and Access level List:

In the example below you will find the steps to import a User List from an Excel file. The procedure to import Door List, Zone List and Access level List is the same.



(Fig. 3)


Next step is to open the import tool and fill the fields:



(Fig. 4)

First of all delect what we want to import (users, doors, etc.) then select the type of file that we want to import. Next step is select the file we want to import, we have to use the browse button to find the file. After this we have to select the start line and finally the page name.

After this we will have to specify the relationship between selected file and SALTO database fields as shown in Fig. 2. The next screen will show a summary where we can see all selected options




(Fig. 5)

Finally a screen with the result of the import will be shown. If any error has happened during the process it will be shown in this window.

Importing Access permissions between Users and Doors, User and Zones, Access levels and Zones or Doors and Zones.

The procedure does not change much from importing users, the main difference is in the Excel File: We have to write the user's complete name, as it is written in the "Name" field in the users profile. If we want to add more than one door to a user we have to make it in different lines as shown in (Fig. 6).




(Fig. 6)

All the following steps are exactly the same as to import User List.

6. Export:

In order to export data from the database into a txt., xls. File we have to go to the menu FILE/ EXPORT/IMPORT/ EXPORT

Once we have selected the option we will see a confirmation window, after pressing we will find the following selection window (Fig. 1)




The screenshot shows the 'Export' dialog box in the SALTO software. The window has a blue title bar and a close button in the top right corner. On the left side, there is a vertical panel with the SALTO logo. The main area contains the following fields and controls:

- Personalized configuration:**
 - Name: users (with a dropdown arrow and a refresh icon)
 - Description: all users
- What do you want to export?:** Users (with a dropdown arrow)
- Type of file to export:** Excel files*.xls (with a dropdown arrow)
- Select file to export:** C:\Documents and Settings\aznar\Escritorio\users.xls (with a 'Browse' button)
- Page name:** Page 1






At the bottom of the window, there are three buttons: '< Back', 'Next >', and 'Cancel'.


(Fig. 1)

We will start giving a name and description to the file, after that we select what do we want to export: Users, Doors, Access levels and or Zones. In the next field we have to select the type of file where we want to export the data: txt or xls. Once we have selected the type of file we will select the file where we want to export the data. Once we have filled up these fields we will press . The following window will appear (Fig. 2)





(Fig. 2)


In this window we will have to select the fields that we want to export and the order by. We have to press  to add fields and  to remove the ones that we don't want. We will use the arrows  and  to change the order of the fields. Once we have made the whole selection we press . We will find the following confirmation window (Fig. 3)



(Fig. 3)

Once we have confirmed all the data we press the  button. We can save the export personal configuration for future applications by pressing .

Once we have completed the exportation, the software will show the following window: (Fig. 4).



(Fig. 4)

7. Administrator operator

The administrator (or administrators) is responsible to design the initial locking schedule of the building and facilities and editing cards that will allow employees access to the various zones and doors.

In this manual, with a view to explaining how this SALTO RW software is used, we have used a hypothetical locking schedule as a sample to illustrate the general procedure.

To begin with, it is important to note that almost every function of the software can be performed by clicking the icons on the Toolbar (except those related to the hotel exclusive data). Parameters can be defined along the way in any order, though it is advisable to follow the order given below:

0. **doors**

1. **zones**
2. **outputs**
3. **time zones**
4. **time periods**
5. **calendars**
6. **time change**
7. **user access levels**
8. **users and key assignment**
9. **PPD usage**

It is important to define time periods, time zones and calendars, before proceeding to PPD initiation of the doors (except for online doors, which can be initialized from the control PC straight).



Doors.

Using this menu option we will create the access control for the users doors (electronic locks and wall readers alike), excluding the guests rooms.

Firstly, move the mouse over the Toolbar icon representing doors.

If it is the first time we open this option, the door list will be empty.




Figure 22

- Click on the NEW button to add the first door to the list.
- In the pop-up window that will be displayed, we will view the fields we will fill in. (Except that of users, which cannot be specified as they have not been defined yet)
- Write the name of the first door.
- You can write a description for the door, if the name is no representative enough.
- ADMIT EXPIRED KEYS:
Door can be set up to admit cards already expired for a certain amount of days. This could be applied to low security offline doors located before an online hotspot, and in order to allow users get access to the hotspot to update their cards. This time can be set up from 0 to 255 days.

Next, we set the characteristics for this door:





Figure 23

- The OPEN TIME field determines the time passed from the moment a user opens a door until the electronic system locks it again. By default, this time value is 10 seconds.
- The INCREASED OPEN TIME field determines an extended open time, especially designed for handicapped or “hands full” people. This time the value is 20 seconds, by default.
- Geographical Time Zones can be set up in the SALTO software to avoid time conflicts in installations with access points in different Geographical Time Zones sharing the same database. This could happen in installations within big countries like Canada, United States, Russia, and Australia, or access points from the same database in countries with different Time Zones, for instance, United Kingdom and Germany.

This is important for the system to apply the different Timed Periods correctly to the access points in their specific geographical area or country , and also for the users in that area or country to have the correct access Timezones in regards to the same geographical area / time zone.

First of all, this feature has to be activated in the General option Menu, General tab, so the option is available in the

software.



When activating the Time Zones, the Time Zone must be specified, as well as the offset from the GMT.


Different time zones can be created just by going to the Data menu and selecting the Time Zones option.



Just by clicking the New button, a new time zone can be created. The Time Zones in the list will be available later on to be assigned to the different access points, and avoid any time conflict with the time base at the database location, and the access points' location, as explained above.


Time Zones can be created from scratch, specifying the GMT and setting up the Daylight Saving time days manually, or the Official Time Zones can be used to set up

the Time Zone, just by clicking the Copy From button, and selecting the Time Zone from the list that will pop up.




Once the Time Zone is selected, the Daylight Saving Time (also called DST) days can be activated. Once active, there are two ways to configure these days:

- Selecting the Standard DST Rule.
- Fixed DST Days: Selecting two days in the calendar, which always will be taken to make the time change.




Once different Time Zones have been created, access points located in different Geographical Time Zones can be set up to follow the time and Daylight Saving Times at that location.



- The OPEN MODE field determines the electronic locks working mode. It can be chosen from the several available:

1. **Standard mode:** the lock will only open if you use an authorised card, within its allowed time zones.
2. **Office mode:** the lock will be opened for any user who wishes to gain access. It is not essential to have an authorised card key. In order to enable this operation mode, it is necessary to insert an authorised key card on the slot while we keep the inner handle pressed down. If you want to disable the office mode, repeat this procedure.
3. **Timed office mode:** It is the same as the operation mode in the previous example, except for a difference that lies in the fact that the office mode can only be enabled within a given time framework, called a PERIOD. Note that the lock will automatically revert to the Standard mode at the end time period. If you choose this mode, you will need to assign one of the opening periods available. Next, you will have to define a period, using the PERIOD tool, from the Toolbar. (As detailed later).
4. **Automatic opening mode:** Quite similar to the previous mode, but the door can switch to and from office mode automatically, without any manual user operation. In this mode it is also necessary to set a time period (defined with the PERIOD tool).
5. **Toggle:** In this mode, presenting a valid user key will set the door in office mode, without needing to hold down the inner handle. The next valid key presented will cancel office mode. This will continue “toggling” the office setting on presentation of each valid user key.
6. **Timed toggle:** This mode works in the same way as Toggle above, with the difference that, you can only toggle the door within a set TIME PERIOD.
7. **Automatic opening + office:** The same as “automatic opening” mode except for the fact that out of the opening periods, the escutcheon can be left in office mode by a user with this attribute enabled.
8. **Keypad only:** this working mode can be only selected for wall readers, never for an escutcheon. The door can be opened by just typing a valid code on its keypad, at any time. This code is defined in the door detail window.
9. **Timed keypad:** same as the previous mode except that the code is only used into a specific time interval (period). Out of the period, we can open the door with the key.

10. **Key + PIN:** this working mode can be only selected for wall readers, never for an escutcheon. The door demands 2 conditions in order to open: a valid key and a valid PIN typed in the keypad. This PIN is defined in the user detail window (later).
11. **Key + timed PIN:** same as the previous mode except that the keypad is only active during a specific time interval (period). Out of the period, it is enough with using the key to open the door.
12. **Exit leaves open (it requires to activate this option in General Options):** The lock remains open when the inner lever is used.




- The door stays opened endless by default. This can be temporized in minutes in “lock” tab option (Tools/Configuration/General options).




13. Toggle + Exit leaves open: it is a combination of the two modes. The entrance with a valid ID works in Toggle (alternate opening and closing) mode while the inner handle will activate the Exit leaves open.

- The box called ZONES shows the door access level that the door we are currently defining belongs to. This box will remain blank until the zones are defined.
- ANTIPASSBACK: Anti pass back is the fact that a user is not able to enter again through the same door twice until he has gone out by the exit. (Or until a specific delay time has gone by). This is a protection against different people try to enter with the same user key.
- In the Salto access control it is also possible to get the anti pass back feature with off line doors. The anti pass back feature is something that is written in the user card.
- The anti pass back check box has to be marked if we want anti pass back control on this door. If the door is an online one, it is supposed that there are an entrance wall reader and an exit wall reader. But if the door is not on line, then it is necessary to select the direction of the anti pass back control – from outside to inside – or from inside to outside-.
- In order to get the anti pass back function working, it is also necessary to select this option for the user, in the user access profile. (User list). We can define the anti pass back delay time in TOOLS/OPTIONS/LOCK.
- If you need to control the entry and the exit then a “Strict” anti pass back is needed. This means that a user won’t be able to go out if he hasn’t came in first. In order to activate the “Strict” anti pass back, go to “Tools/ Advanced Options and on Locks Tab” as you can see in the next picture, and check the “Enable strict anti pass back” check box.



When reading the card and clicking on the “Content>>” button we’ll get the following information.




If the Anti pass back option is being used, this window will show the information present on the card (“In” access in the example) with the date and time the card was presented on it.


- The AUDIT ON KEYS check box can be marked if we want the escutcheon to record the opening events on the staff

keys. You need to enable this feature on both escutcheons and keys (users).

- On Calendar it can be selected one of the calendar configuration created. This is useful when we have doors in different geographical areas with different calendars configuration.
- Audit inside handle opening is used to audit the exit of the user through the use of the inner lever.




- On line features are only available in the PA software connected. Not in the standard PA software.
1. If the door is a wall reader with online control unit (CU50EN, CU50ENSVN) then, you have to mark the check box IS ON LINE. The CONFIGURE CONNECTION BUTTON is used to assign an IP address to this device and initialize it at the same time.
 2. The UPDATE DOOR button can be used to transmit new information to this online door when changes are made.



The CONFIGURE CONNECTION button and the UPDATE DOOR button won't be enabled until you save the changes for this window. Now, we are going to initialize this door as it is an online one:

- Press the CONFIGURE CONNECTION BUTTON.
- You will get a window like the following:



- It is necessary to write the IP address we are going to assign to this device in our local area network. Then save the changes.



- Consult your LAN administrator if you are not sure about which is the IP address we should give to this control unit. Then someone has to press the CLR button in the control unit circuit during several seconds until the LED starts blinking in the CU. In that moment, you have to press the ADDRESS button in the software.
- If you do not get an error message, it is assumed that the IP address has been assigned properly. Also, the device has been initialized at the same time.
- The SIGNAL button can be used with Ethernet encoders but not with wall readers. It makes the encoder to beep and blink for a while.
- On line devices can be created from the door list or from the PERIPHERAL LIST, the result is the same for wall readers. (Ethernet encoders can only be created from PERIPHERAL LIST).
- We can go creating more doors for the DOOR LIST, no matters if they are online doors or off line devices.
- In the bottom left-hand side of the window there are some scroll arrows that will pass us from the previous door to the door immediately after (< >) or rather, move to the first or last door of the list.
- On the right-hand side of the window there is a box called THIS DOOR IS BEING ACCESSED BY... USERS. Here

there will appear those users with access rights to this door, after we have set the users.

- The box called THIS DOOR IS BEING ACCESSED BY...ACCESS LEVELS, will also present the user access levels with access rights to this door, once the user access levels have been defined (Later in this manual).
- Once we have completed the door definition, we can save the changes and define the rest of the doors the button +.




Figure 24

When you complete the door definition, you can obtain a door list like the following:



Figure 25

- When we have this window active, and want to view the characteristics of a particular door, we just have to select this door in the list and click on the *VIEW DETAILS* button.
- If, by mistake, we have written a door in the list that should not appear, we must simply select it and click on the *DELETE* button.
- The field **BATTERY** shows the battery level, once the PPD has been connected back to the PC after the first initializing procedure. Now, this information is not available yet.
- The field **BATTERY STATUS DATE** shows the date of the last PPD connection which supplied this information to the PC. So, the battery level shown is only real when this date is recent.
- A box on the upper part of the list called **SORT** can be used to re sort the list order. If you click here, you can change the order in which the doors will appear, so that they appear in order by name or by battery status, or by open mode.
- The **PRINT** button can be used to obtain a hardcopy report from the door list. You can select between printing all of the door list or just the details that relate to one particular door.



Zones.

In this section we will explain how to use the zone list. Zones being defined as an access level of doors that have been grouped for reasons of practicality, for instance, the doors located on the first floor, on the second floor, etc.

On the Toolbar, click on the *ZONES* icon and you will be shown a window like the one below:




Figure 26

- Click on the *NEW* button in order to create the first zone of the list.
- A blank window like this will be displayed:




Figure 27

- Firstly, type a zone name.
- In the field DESCRIPTION you may type an explanation on what basis you have gathered together these doors.
- The check box LOW ZONE should not be modified unless our locking plan needs more than 96 different zones. Zones are classified as low or high according to the way zone information is stored on escutcheons. You are allowed to create up to 96 low zones and 928 high zones. Once this check box has been modified and changes saved, it is not possible to modify it again. From the escutcheon point of view, you can make a given door belong to a maximum number of 96 low zones, but only 20 of high zones.
- The box called DOORS BELONGING TO THIS ZONE is used to list all doors within the zone. Move the mouse over the +/- button to view the doors list and pick up those that you want to belong to this zone.




Figure 28

- Move the mouse over the door you want to select to include in this zone group, and then, click on the yellow arrow these points at the right column.
- The door selected will appear on the right-hand side column as an integral part of the zone.




Figure 29

- Repeat this operation as many times as doors you want to incorporate to this zone.
- When you fill up the right-hand side column with the doors required in this zone, click on the OK button.
- At this point, the doors belonging to this zone will be shown in the bottom left-hand side box, within the zone detail window.
- The tag called ACCESSED BY... USERS is left blank since we have not yet defined users. Once we have defined them, we would use this box to specify which users will have access to this zone (and on what time zone basis)
- The tag called ACCESSED BY... ACCESS LEVELS works similarly to users, except for the fact that instead of assigning accesses to the zone individually, accesses are assigned collectively, as a access level. This saves time.
- When you have filled in all the fields of this zone detail window, save the changes.




Figure 30

- If you click on the + button, you go on to the next detail window, and thus, you can define the whole set of zones for our installation.

In the following example, a zone comprises of 1 door that gives access to the swimming pool.




Figure 31

- Finally, we would have a zone list like the one shown below:




Figure 32

- Should we have created a zone by mistake, you will only have to select it with the mouse and click on the DELETE button.

- If, after we have saved changes, we want to view a zone details from the list, you only have to select it with the mouse and click on the VIEW DETAILS button.
- Should we want to select a zone from the list without the mouse, we can also use the scroll arrows located on the upper right-hand side of this window <> , to move forward to the next element of the list, to move back, or also, to go directly to the first or to the last elements of the list.
- The box called SORT BY is used to sort the zones list alphabetically, by zone name, or by zone description.
- The PRINT button can be used to obtain a hardcopy report from the zone list. You can select between printing all of the zone list or only the details that relate to one particular zone.



Outputs

It is possible that one control unit is connected to a relay extension board, so one allowed user will be able to activate only one or several relays, for example, in an elevator. In our example, guests in second floor will be able to go to second floor using the elevator (and also ground level) but they won't be able to go to first floor using the elevator.


In our example, we have also 2 elevators, but they give access to the same areas, so the outputs relating every elevator, are the same, Output 1= first floor, Output 2= second floor. Output 3= ground level.

We have to create so many outputs as relays the extension board is going to control, and then these outputs can be assigned to users and guest access levels, in the same way zones are assigned. It is very important to have into account the fact that in order a user is able to activate one relay, he needs to activate first the wall reader which is linked to this relay extension board.


In our example, we are going to create 3 outputs, for the relay extension board.

The first output will be the first floor (for elevators 1 and 2) and the second output will be the second floor (for elevators 1 and 2). There is a wall reader mounted into every elevator cabin.

So, let's go to DATA/OUTPUT LIST:




Here, we can define the different relays in the relay extension board and explain the use of that relay.



It is very important to remember the numbers assigned to every relay, as the number (output number 1) matches physically the first relay, in the relay extension board. We can write the name and description, and then save changes.


We can go creating outputs until the output list is complete.




Then, these outputs will be assigned to users and guest access levels in the same way we can assign zones. It is very important not to forget to assign to these users, the elevator wall readers, as a door. So, they will be able to command the outputs linked to these wall readers.

Automatic Outputs:

If we want some of the outputs from a door to work on an automatic opening mode on a specific time period we will need to assign this time period to the outputs in each door. Go to the door/room details:



In the following window:



Just add the outputs and the selected time period.

NOTE: The maximum number of timed outputs is 4.



Time periods.

Time periods are time intervals associated to the electronic locks (unlike time zones that are associated to people). A time period determines the time intervals at which a lock will operate in a special mode – timed office mode, automatic opening mode-.

If at the time you performed the door definitions, you selected a timed operating mode for any of these doors, you will have to use time periods to define the period assigned to that door.




Figure 33

- Click on the time period icon on the Toolbar. A window like the one shown in the previous figure will be displayed.
- Name the Time period and assign it a distinctive colour.
- Within the description field, it is rather useful to describe the doors that belong to the time period we are about to define.




Figure 34

- The time period is defined using the mouse. Click with the mouse on the upper triangular slider and drag it to the desired interval beginning time.
- Click with the mouse over the lower slider to set the time interval end. Maximum time accuracy is 10 minutes.
- Afterwards, you will have to specify on which week days this period is going to be applicable. You can also adjust if it is to operate on public holidays or special holidays (these buttons relate to calendar 0, as this is where public holidays and special holidays for time periods are defined)
- The system applies the period to every weekday, by default.
- If the time period we are defining contains several time subintervals, we will use the number of lines necessary to define it.
- When you have finished defining a time period, save changes and you can then go on to define more periods for the system.
- The PRINT button can be used to obtain a hardcopy report for the time period list. You can select between printing all of the list or only the details that relate to one particular period.

- Do not forget to assign the time period to its corresponding door, if you have not assigned it previously. In order to do so, go to DOORS and choose the door that requires a time period. Click on the VIEW DETAILS button and you will see the list of periods that you previously defined. Select the time period applicable to this door and save changes.




Figure 35



Time zones.

Time zones are time intervals to which people belong (unlike time periods that belong to doors). A Time zone is the interval of time in which a user has access to a particular door or zone.

- To define time zones, click on the TIME ZONE icon on the Toolbar.
- A blank window like the one below will be displayed.




Figure 36

- Type the first time zone name and assign it a colour.
- Within the description field, it is very useful to type the name or names of people that this time zone belongs to.
- In order to define this time zone, we must follow the same procedure as in time periods, as explained in the preceding section.
- Remember to specify on which week days the time zone will be effective, as well as whether that time zone will be effective on public holidays or special holidays. You just have to highlight off the corresponding check boxes with the mouse, if you do not want the time zone to be operative on that day.
- Once time zone definition is completed, save changes and go on to define further time zones for other users or user access levels.
- You can use the PRINT button to obtain a hardcopy report from the timezone list. You can select between printing all of the timezone list or only the details that relate to one particular timezone.




Figure 37

- Remember to assign the time zones to users or users access level, as is detailed later in the user and users access levels definition section.



Calendars.

- It is essential to define calendars within our locking schedule for two main reasons:
 - The calendars range available is from 0 to 255. And each of them can be selected for the escutcheons and for the users as well.
 - For the escutcheons the calendars are used when they operate in timed mode(timed office mode, automatic opening mode) so as to define on which days their periods are to be applied. This is also the calendar assigned to users without expiration date in their keys.
 - Concerning the users, to define on which days their access time zones are applicable.

To define our calendars, you just have to click on the calendar icon on the Toolbar.




Figure 38

- A window like the one above will be displayed. We can name our first calendar and provide it with a relevant description.
- It is advisable to define the calendar for the current year and for the following year, if possible. To go to the next year you have just to click on the red scroll arrow on the upper part of the window.
- There are four categories for each day: Normal, Holidays, Special 1 and Special 2 and 9 calendars for users.
- Using the mouse you can tick off a group of days in the calendar. Drag the mouse whilst you keep the right mouse button pressed down.
- Next, you must click on the box in the lower part of the screen which corresponds to the day category you want to assign to this group of days, and you will see how the days selected change colour according to their type selection.
- It is important to bear in mind that if a user has access to a door on public holidays, it does not depend only on the

calendar but also on that users time zone being enabled for holidays or special days.

- When you have completed calendar definition, you will obtain something similar to the figure below.




Figure 39

- Save changes when calendar definition is finished and continue to define the next calendar, if your installation requires it.
- The PRINT button can be used to obtain a hardcopy report for the calendar list. You can select between printing all of the calendars or only the details that relate to one particular calendar. The types of day will be recognised by a letter, H for Holiday, S for special day, N for normal day.




Figure 40

- Remember to assign the different calendars (1 and 2) to the different users and user access levels, as is later detailed in the user and users access levels definition section.
- The same for the escutcheons.



Time change.

DST stands for the English Daylight Saving Time, that is to say, the time change that takes place with a view to saving power by means of daylight optimisation.

This time change is generally made shortly after vernal equinox and autumnal equinox, putting time forward in the former and putting time backward in the latter.

Salto electronic locks perform time change automatically, if it is set up in the software.

Click on the DST icon on the Toolbar and you will get a window similar to this:





Figure 41

- You can either enable (or not) time change by ticking off the ENABLE DTS check box that is located on the bottom left-hand side of the window.
- You may also change the time at which the time change DAY and HOUR takes place, using the bottom right-hand side arrows of the window.
- If you modify time change day, the symbol that embodies it will be moved in the calendar accordingly.




- You can also set the time change for next year, if you wish. Click on the red arrow (right) of the window upper part, to move on to the next year.
- Save changes when you have finished establishing appropriate parameters for time change.
- It is recommended to enable automatic time change, since if it is not software enabled, you will have to update every door in your hotel using the PPD, on the scheduled date of the change.


Output List for Electronic Saving Devices (ESD)

It is possible to use ESD under Salto ProAccess using the outputs option.

The selected user must have access to one of the two outputs (or both) available under Output list menu. Output 900 will activate relay1 and output 901 relay2.



The ESD is created from Doors menu the same way as a normal lock. The only information to use is the name (the rest of params won't be sent to the ESD).



Automatic changes

Starting from version 6, the RW software supports automatic changes. This is a new open mode for CUs. Unlike the open modes we have known so far (for example, OFFICE), automatic changes allow CUs to vary their open mode along different time intervals. For example, from 00:00H to 08:00H -> OFFICE mode, from 08:00H to 18:00H -> AUTOMATIC OPENING and from 18:00H to 24:00H -> STANDARD mode.

More specifically, an automatic change is a time interval in which the CU works in a defined opening mode. Thus, three parameters define an automatic change: start time, end time and opening mode. For a given day type (normal day of week, holiday, special 1 and special 2), up to 8 automatic changes may be declared. In order to allow different combinations, the RW software groups different day types (and their associated automatic changes) into 256 tables.

In summary, the SALTO DB includes 256 automatic change tables, where each table contains the 10 day types (Monday to Sunday, Holiday, Special1 and Special2) and each day type, in turn, may contain up to 8 automatic changes.

As for the graphic interface, the 'DATA\TIME PERIODS...' menu option now shows two more sub-options, namely, Time Periods and Automatic Changes, as shown in the picture below.




Figure 1: accessing to the automatic changes window through the main menu.

The picture below (figure 2) shows the window that allows setting up automatic changes. Within this window you may modify the automatic changes of a given table and day type (through the corresponding '+/-' button) as shown in figure 3. You may also copy automatic changes from one day type to another (through the '=' button) as shown in figure 4 or even copy a whole table into another (through the '= Copy' button) as shown in figure 5. Finally, you may make a given CU works in automatic change mode as shown in figure 6.




Figure 2: automatic changes window.




Figure 3: modifying automatic changes of a given table and day type (button '+/-').




Figure 4: specifying the table and day type from which you want automatic changes to be copied (button '=').




Figure 5: specifying the source table and the destination table for automatic changes to be copied (button '= Copy').




Figure 6: making a CU work in automatic change mode.



Users access levels

It is advisable to take heed of the fact that users are hotel personnel (staff) members, but *never* guests.

Users access levels are definable groups of users, that share a common feature: For instance, we can group together users by job type or department, like cleaners etc tend to share time zones and accesses.

Click on the USERS ACCESS LEVEL icon on the Toolbar:

A window like this will be displayed:




Figure 42

- Since we have not created any user access levels yet, the list will be empty.
- To create the first users access level, click on the NEW button.
- A window like the one below will be displayed:




Figure 43

- Firstly, type this user access levels name, and below, a description detailing the main characteristic that best defines the access level.
- Given that we have not defined users yet, we cannot specify the users that belong to the access level, though we can establish access level accesses.
- In the tag called ZONES BEING ACCESSED, click on the +/- button to assign door zones to the access level.
- If a user must belong to different access levels there are two ways to do it,
 - 1/ into the Access lever window, as shown in Figure 44, we add users into the list using button +/-, for each of the access levels where we want the user to belong to.
 - 2/ in the user accesses, located into the user list, we can add the previously created Access levels as shown on Figure 44b.

On the other hand, the user can also have Accesses to separate doors.




Figure 44





Figure 44b


- We have to move from left-hand side to the right-hand side column, the zones that are going to be accessed by this group of users.
- If we have included a zone by mistake, highlight it in blue color, and click on the yellow arrow pointing left, to put it back to the left column.
- Yellow double-arrow performs the same function as single arrow, but instead of moving an individual zone, they move all zones from source to target column.
- In this window, we can specify to which zones the access level is allowed access, (clicking on the +/- button), and we can also determine group time zones, (clicking on the hourglass symbol).

- **Authorizing an access level access into a zone implies that all the users who belong to that access level, may enter every door of the zone.**



In the access level details window there is a tag titled DOORS BEING ACCESSED. The procedure for completing this box is similar to that of the ZONES BEING ACCESSED box, the only difference is that instead of assigning accesses by zones, they are assigned by individual doors. This option may be used for a single door, but access by door zones management is generally recommended, as this saves time and chip (key) memory.

It is also necessary to assign outputs to this user access level, if necessary. The tag OUTPUTS works in the same way as zones or doors, and here we can select the relays that are going to be commanded by this user access level.



This way the complete access profile for this user access level is designed.





Figure 45

- When you have specified every single characteristic of this user access level, save the changes and go on to define next access level by clicking on + button.
- In the example here, a time zone for cleaning personnel has been set up. Assigning accesses to the *cleaners* group, we can also assign them time zones using the hourglass symbol.
- If no time zone is assigned to a door or zone of doors, by default, the system sets a 24 hour access to the access level.



- Finally, the user access levels list will look like this below:




Figure 46

- If we have created an access level by mistake, just select it in blue color and click on the DELETE button.

- If at a given point, we want to view the details of an access level of the list, simply select that access level and click on the VIEW DETAILS button.
- Another way of selecting an access level from the list is with the |< >| scroll arrows that are located on the upper left-hand side of the window, instead of using the mouse.
- The box on the upper part titled SORT BY is used to sort user's access levels list in alphabetical order, by name or by description.
- The PRINT button can be used to obtain a hardcopy report from the user access level list. You can select between printing all of the user access level lists or only the details that relate to one particular user access level.



Users.

In this section we will define the users characteristics.

Click with the mouse on the USERS icon on the Toolbar.

A window like this one will be displayed:




Figure 47

- Given that it is the first time we have opened the users list, the list is empty.
- Click on the NEW button to create the first user.
- A window like this one will be displayed:



Figure 48

- Type our first user name and surname.
In the situation where more than one person has the same name, it will be necessary to define the users ID composition. To do so, go to Tools/ Configuration/ General options and users tab, as shown below;




As you can see on the previous image, the user ID can be set up with the information contained on various fields as;

- 1/ TITLE
 - 2/ FIRST NAME
 - 3/ LAST NAME
 - 4/ GPF1
 - 5/ GPF2
 - 6/ GPF3
 - 7/ EXT USER ID
- I.E. User ID= GPF1 or User ID= GPF1+LAST NAME+EXT USER ID.


- We have the ability to assign a calendar to our first user, according to the calendar settings we have previously defined.
- We have to specify which user access level this person belongs to. As we have already created users access levels, then we must select one for this user.
- We get a check box titled USE EXTENDED OPENING TIME. Tick this check box if our user is a handicapped person.

- The OVERRIDE PRIVACY check box must only be ticked when we want a user to have the privilege of accessing a guest room even when the door has been locked from the inside.
- The SET IN OFFICE check box may be ticked to allow users who are responsible for setting doors into office mode to do so.
- The USE ANTIPASS BACK check box may be ticked off to allow this special access mode for users who must have it, in the doors where this access mode has been selected. The anti pass back time can be selected in TOOLS/OPTION/LOCK, in hours and minutes.
- If a user has not got the ANTIPASS BACK check box ticked off, this user will have a standard access, so he won't have any restriction to enter twice by the same door.
- The check box AUDIT OPENINGS IN THE KEY can be marked if we want this user to have his personal audit trail on his key (recorded by doors).
- In the lower left-hand side you find a box titled KEY STATUS. In this box will appear the characteristics of the card assigned to this user, when user keys have been assigned.
- The box titled KEY UPDATING displays information about the key updating procedure.
- Doors working in Keypad Only mode could have their Code changed by one of the users that have got access through it. This option is normally useful in Dormitory Entrances, where the dormitories users' turnover requires a code change from time to time, in order to avoid security issues.




In order to activate this function, the DORM_KEYPAD=1 parameter has to be added to the Advanced options, in the


General Options menu. This is only available in Pro Access For Service.



This option will activate the “Dormitory Door” option in the User set up window. When a dormitory door is selected, the user (or users) will be able to change the keypad code in that dormitory door.



The door’s code has to be changed in the Door set up window, changing the original code in the Keypad code field.




Once the code is changed, the user will have the new Keypad code written on its card when the card is presented at a SVN hotspot. As soon as the card is presented in the Dormitory door, the Keypad code will be updated, invalidating the previous one.


- The check box WITH EXPIRATION should be marked if we want this key to be updated with a particular frequency, in the SVN wall readers. If we do not mark this check box, it is assumed that we do not have SVN and there is no key update (except through encoder.)
- **DEFAULT EXPIRATION IN DAYS AND HOURS.**
Default Expiration Period for users can be set up to a certain amount of days or hours.
In case DAYS expiration time is selected, bear in mind that the last day of the expiration date would have to pass in order for the card to get expired. For instance, if a card is encoded on Monday at 08:00, and the Default Expiration Period is set up to 2 days, the card will expire on Wednesday at 24:00.
In case HOURS expiration time is selected, the expiration would be precise, that is to say, if a card is encoded at 16:06 hours, and the Default Expiration Period is set up to 4 hours, the card will get expired at 20:06.



- Users without expiration date are only allowed to use calendar 0.
- The UPDATE PERIOD box means how many extra days are added to the expiration of the key when updating in a CU50ENSVN.
- The check box LAST UPDATE DATE means the end of updating procedure for this key. After this date, the key won't be updated any longer. It is not mandatory to establish a last update date for a key.
- KEY WITH A QUESTION MARK BUTTON: this is a tool to show the key structure data. (such as header size, number of auditor records, consumed memory percentage, etc...)



- **KEY CALCULATOR BUTTON:** this tool can be used as a preview for the key structure information and memory consumption before any actual encoding is done. This tool works as a simulator for different technologies (smart. lbutton, proximity).



- It is not essential to define user accesses when this user belongs to an access level, since the user will have access level accesses as previously defined.
- Only when the user is not included in any access level, would you assign accesses at this point.
- It is not compulsory to assign the same time zone to different zones.



Figure 49

- Assigning a door zone to a user, will grant the user access to every door that is included in that zone.
- When we have a user that does not belong to any access level, we can assign his accesses from this window by following the procedure explained in the USERS ACCESS LEVELS section of this manual.
- The user and card expiration are managed from the following options
 - **User expiration** sets the maximum user validity
 - **User activation** sets the date since the card will be functional
 - **Enable key revalidation** sets the period the card will be updated for (in days or hours)

User and key expiration

User expiration

26/12/2008 16:37

User activation

15/12/2008

Enable key revalidation

Update period

30 (Days) (Hours)

- Once we have finished defining user characteristics, save the changes and click on the + button to go on to the next user in the list.
- When we have all the users (staff) defined, we will obtain a list that should look like the following:

The screenshot shows a window titled 'User list' with a table of user records. The table has columns for Key status, User status, Max. access date, Key expiration, Name, Group, Calendar, and Office. The data rows are as follows:


Key status	User status	Max. access date	Key expiration	Name	Group	Calendar	Office
		22/11/2007 00:00		John MacFay		Calendar0	
		22/11/2007 00:00		Peter Coyote		Calendar0	
		22/11/2007 00:00		Phil Harvey		Calendar0	
		22/11/2007 00:00		Richard Widmark		Calendar0	
		22/11/2007 00:00		Roger Miller		Calendar0	

At the bottom of the window, there are several buttons: New, View details, Delete, Print, Close, Make user banned, Refresh, Key assignment (Assign key, Cancel key).

Figure 51

- If we have inserted a user by mistake, we can delete it selecting it first and then, clicking on the DELETE button.


- To view the details window of a given user, select the user and click on the VIEW DETAILS button.
- We can also use the scroll arrows on the left-hand corner to select a user from the list, instead of using the mouse to do so. With these scroll arrows <>, we pass to the user immediately after or before, and with these arrows |< >|, to the first or last users of the list.
- The box called SORT BY is used to sort users list according to the most convenient criteria, by name, by surname, by calendar, by access level, by expiration date...
- The PRINT button can be used to obtain a hardcopy report for the user list. You can select between printing all of the user lists or only the details that relate to one particular user. (a user profile).
- The Make user banned is an option to block a user. So any change or modification can be done on him. It can be configured on the operators and permissions the operator who will have the privilege to make banned a user. When a user has been banned and he presents the card to the CU the access plan is going to be erased and that user won't be able to access to any part of that installation. As soon as the same user has been disbanned and presents his card to the CU will be again updated with his access plan.
- Picture. A picture can be added to identify the user. The photo can be imported from any storage device (hard disk, USB pendrive, memory card,...) or directly from a connected camera device. Many picture formats are compatible (jpeg, bmp, tif, gif,...).



Picture aspect

The picture aspect can be predefined from the General Options menu, user tab. The options are:

3:4
2:3
1:1



User key assignment

Once you have completed user list definition, we can then proceed to assign each user their key (Smart Card, Ibutton , proximity.) In order to do so, you must connect the ENCODER to the serial port of your computer. You must also supply power to the ENCODER plugging the feeder provided to a 220-240 V. AC, 50 Hz socket and inserting the respective jack into the ENCODER.

To assign user keys, follow the steps detailed below:




Figure 52

- From the user list, highlight a user with the mouse. Then, click on the ASSIGN KEY button that can be found on the lower right-hand side corner of the window.




Figure 53

- The system will prompt a message window requesting you to insert a card into the ENCODER.




Figure 54

- Encoding process is very swift. The system will tell you to withdraw the card almost straightaway.
- Now, you will check that a yellow key icon appears next to the user name to which key has been assigned.




Figure 55

- You are encouraged to hand the keys over to respective users without any delay.
- To further assign the keys to other users, follow the same procedure.
- Finally, you will obtain a user list with their key assigned, as shown in the following figure:

Key status	Key expiration	Last update date	Name	Group	Calendar	Office	Overwrite previous	User email
	31/10/2009 12:00		Eugenio Aparicio	managers	Calendar1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
	31/10/2009 09:50		Rafael Bolaño	reception desk	Calendar2	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
	31/10/2009 12:00		Maria de la Torre	cleaning personnel	Calendar1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
	31/10/2009 12:00		Cristina Fuentes	reception desk	Calendar1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
	31/10/2009 12:00		Andrés Gómez	cleaning personnel	Calendar2	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
	31/10/2009 12:00		Lucas Lopez		Calendar2	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
	31/10/2009 12:00		Andrea Martinez	managers	Calendar2	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
	31/10/2009 12:00		Pedro Rubio	cleaning personnel	Calendar1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
	31/10/2009 12:00		Eneque Zabala	maintenance	Calendar1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	

Figure 56

- If a user loses a key, you must immediately cancel it in the user list. To do so, highlight the user that has lost their card, and click on CANCEL KEY button.
- Afterwards, a new card for this user has to be edited, following the same procedure as previously detailed. From now on, the user will have a new card. However, should for any reason whatsoever the lost key turn up, this will no longer open any of the doors where the new key has been used.
- If we modify any users access rights, we will have also to update the users key. To accomplish this task, you should ask the user for their key so as to allow you to update it on the ENCODER.
- The colour of the icon of the key denotes its status. Thus, a red key means that it has changes to be updated; a blue key

means that its expiration date is approaching and a yellow key with an hourglass means that it has already expired.

- There are 2 reasons for a key appearing in blue colour: 1. The key is going to expire in the next 15 days but it was edited more than 15 days ago. 2. The key is going to expire in the next 7 days but it was edited more than 7 days ago.
- Once the key has been assigned to the user, any change made in the user access profile will imply the key turns red colour. This changes can be updated in the SVN wall readers but there are 2 specific changes that imply “key re-edition” or “key re-encoding”. These are ANTIPASSBACK and AUDIT ON KEY option. (for the users).
- When one of these changes is made, the key will appear in red colour with a cog symbol, to remember you need to update the key in the serial encoder – “re-edition”. See image below.
- The fact of changing the antipass back time, TOOLS/OPTIONS/LOCK also implies re-edition for the user cards , although the cog symbol will not appear next to the key symbol, in the user list.

If there is any doubt about the need of re-edit the user cards, this can be cleared by the light signals given by the Salto Virtual net wall reader.

The light signals are different depending on the technology:

- Smart card: orange flashing light (key is being updated) followed by a fix light red or green (door close, door open). This is the standard sequence. If after that there is a fixed orange light, then this means that the key needs re-edition.
- I button and proximity cards: blue flashing light (key is being updated) followed by a fixed light red or green (door close, door open). This is the standard sequence. IF after that there is a fixed blue light, this means that the key needs re-edition.

I-Locker.

SALTO includes in his software the option to manage as web the iLockers. The configuration and use of them is very intuitive and similar to our escutcheons and permits us as well obtain the same info as we get from our escutcheons (Openings, rejects, etc.)

Free Assignment Zone:

We can either assign an iLocker directly to a User (like with the escutcheons) or there is another option where the user can choose freely the iLocker that he wants to use.

In these cases we have to create a Zone including all the iLockers where users will choose a free one. The procedure to create this Zone is similar to create a Door Zone.

Define iLockers:

First of all we have to include the iLockers in the software. To do this we have to go to the menu DATA/ LOCKERS. The following window will be shown (Fig 1). In this window we will see the iLocker list, the status (open/close), Name, Battery Status, Date, Opening Mode and Time Zone.

In the bottom part there is a check box "Show only closed Lockers". If you enable this option only the closed Lockers will be shown in the screen. There is another button "Set Locker state as opened". This option is very helpful when a user has left the iLocker closed and we open it with a master key. In this way we can change the state manually.



(Fig. 1)

Next step will be to press the “New” button and start defining the iLockers profile. The procedure is similar to create a new door. (Fig 2).




(Fig. 2)

We have to define the profile:

Select opening mode (Standard or Automatic Opening). If the iLocker is going to be included in a “Free assignment Zone” it is very important to enable the checkbox “Is free assignment locker”

Define Free Assignment Zones:

To enable this option we have to go to the menu: TOOLS/ CONFIGURATION/ GENERAL OPTIONS/ ADVANCE and enable the option “Free assignment Locker”




(Fig. 4)

In this case we have to enable the checkbox “Is free assignment zone”. **It is very important that we have defined the iLockers as “Free assignment Locker” otherwise the software will show us an error message.**


Free Closing:

The free closing option will allow a user or a group of users to close the locker without the need to present a key. The thumb turn stays closable every time it is opened. The keys will have to be configured as Static keys. In example, this configuration could be used for common lockers used by a few users for medicines or some components in a store.



Types of Keys:

If we go to the menu TOOLS/ CONFIGURATION/ GENERAL OPTIONS/ KEYS we will be able to select different types of keys that we want to use in this zone.



(Fig. 3)

- **Dynamic Keys:** This type of key allows users capture any Locker from a Free assignment Zone and after he has leave it empty can capture again another different one from the same Zone.
- **Static Keys:** In this case the user can firstly close any locker from the Free assignment zone. However, after he has empty it he can only capture the same one.

Set locker state as opened this function is the same one as we can find in the “Locker List”

Time-limited Occupancy:

This option limits the occupancy of a locker. We have to fill the boxes and give the time in hours and Minutes.

Note: If this time expires ONLY a master key will be able to open the locker.

Reset timing when re-capturing locker: This option allows reset the timing of a Locker.

i-Locker & Visitors:

In the menu: TOOLS/ CONFIGURATION/ GENERAL OPTIONS and in the Key tag there is a checkbox "Control of lockers left closed". This option will show if the Visitor has left the locker opened or closed (Not allowing other users use this locker) when we make the Visitors Checkout.

ILocker Initialisation:

To initialise the iLockers we have to follow the normal procedure. We select the lockers that we want to initialise and load them to the ppd. Once we have initialized them we have to download again this information to the software.

ILocker number information:


It exist the possibility to obtain information about which ILocker has been captured by a user with the key.

In order to do so, it is necessary to have a dedicated PC with its own screen and a Salto key encoder.

In the Salto application shortcut properties, it is need to write after the default target "...exe" **/ILOCKER_INF** at the end of the line.




Then you will see a window as shown below, which indicate what ILocker has been captured with the key just by showing the key to the encoder.



On the other hand, well as display the name of the locker, it is possible to reset the key counter in case that it is corrupted or cannot open the locker.

To do so, it is necessary to write the following text on the Salto software shortcut properties; "...exe" **/ILOCKER_INF_RESET** as shown below.




After the reset, the user will be able to open his locker but also any other free locker.

WARNING; In case the user capture another locker, it won't be possible to capture again the locker captured before the reset. On the other hand, the user will only be able to read what locker is captured once, because after the reset, this information will disappear.

Visits:

The software allows as well Visitors managing, we define as Visitors, those people not included in our database and that are going to have temporal accesses to the system due to different reasons. In order to activate the Visitors features we have to go to: TOOLS/ CONFIGURATION/ GENERAL OPTIONS and then click on the **Visitors** tag. (Fig 1)




(Fig 1)

We have to enable the checkbox “Enable Visitors”. The next box will show us the default checkout time. This time can be modified when we make a visit checkin. The second box enables the track (track 1, track2, track 3) if we want to write extra information in the card. In this case we have to determine the character size for this option. On the last box we can delimit the maximum number of days for each visit. That parameter will delimit the expiration date checking out the visit.

Once we have enabled Visitors, we have to define the Visitors profile. To do this we have to go the menu DATA and select VISITORS PROFILES. A Visitor Group List window will appear, we have to create a new group. The method is similar to create a new User access level, we


have to define the accesses and timezones as well as if these accesses are optional. This is important as if we make them optional they will appear as such when we make a checkin. (Fig. 2)



(Figure 2)

Visitors Checkin :

To make a Visitors checkin we have to go to the menu Keys and select « Visitors Checkin » or press F10. (Fig 3)



(Figure 3)

We have to fill the following fields:

- Name
- Start date and time
- Expiry date and time , the maximum date available will depend on the number written on the maximum number days on the visit general configuration.
- Access level
- Give any optional facility and Additional data
- Finally Edit the key.

In this window there is a button “Show Visitors”. This option will allow us to see all active visits that we have (Fig. 4)



(Figura 4)

Checkout visitors:

To make a checkout we have to go to the menu Keys and press Visitors checkout or press F11.



Blacklist

The blacklist is a virtual list where are placed canceled user keys IDs. Once a key has been canceled, the ID is sent through our virtual network called SVN. Every online SVN wall reader will update the users' keys with the blacklist information. At the same time all updated keys will update the offline escutcheons and wall readers, this way, the information concerning the canceled key will be spread by the keys containing the blacklist information.

Blacklist Configuration

The software allows the creation of an unlimited quantity of users, 4 million user keys but only maximum of 64000 keys will be able to be cancelled through blacklist.


Once the blacklist arrives to its maximum, 64000 canceled keys, the blacklist won't be sent through the SVN virtual network to the keys; this is why it is IMPORTANT to understand this concept in order to manage it the best way.

By default, all the users are sent to blacklist when canceled, therefore the software allows to select what users will be sent or not to the blacklist when canceled.

To do so, select the advanced parameter into the general options, advanced tab; MORE_THAN_64K_USERS=1, as shown on the image below;



Once this parameter is saved, a new option will be shown on the user list to select what users can be canceled through blacklist.




If the option is selected, a canceled user will be sent to blacklist and the information will be spread to all the units through SVN.

In case it is NOT selected, the canceled key won't be sent to blacklist. It is important to know that in this case there is only 2 ways to invalidate this canceled key;


1/ the canceled key is presented to an SVN online wall reader. The wall reader will DELETE the key immediately; this will avoid the key to open any door, online as offline.

Therefore, the wall reader won't update other users' keys with the information of the blacklist for them to spread it.


2/ the key expire. For this reason, when un checking the "cancel key through blacklist" option, the revalidation period will have to be changed to a maximum of 7 days.



If the revalidation period is higher than the planned, by default 3 days, the following message will appear.



In this case, the maximum expiration period allowed is 7 days, as shown below, therefore, by default it is configured to 3 days because of the fact that as lower is the period of expiration as higher will be the security, if the key expires as soon as possible.





Automatic key up date

There is an option in the KEYS menu, called AUTOMATIC KEY UP DATE, which allows you to update the user cards without needing to go to the user list and select the required user.

This function leaves the encoder in the requesting key status, and it will automatically update user access profiles, (new and eliminated user cards), on every user card inserted. It does not matter in which order the user cards are inserted. The expiration date given to these cards will be the same for all users, and it is the value stated at TOOLS/OPTIONS/USER, in days.

This function allows the system administrator to make the changes in the user profiles, without needing to manually up date the cards one by one.




Using PPD. Initialization

The PPD is a Portable Programming Device used to communicate with the locks and transfer data from the PC on the locking schedule we have designed. Should you have any doubts on

this device usage, please, refer to the PPD Smart User's Manual that you will find included in the RW software CD-ROM.

Main menu:

Below, you can review a diagram of PPD menu options. It is important to note that all these options will not always be present, depending on their being enabled or not from the management computer. As default value, DIAGNOSTIC and COLLECT OPENINGS options will be present, although we have not enabled them on the computer.



Initializing doors:

When we have our locking schedule finished on our computer, we must transfer all the data from our computer to the portable programming device.

We will initialize every door granting it a name that will be definitive from now onwards.

Ensure that your computer clock time (on the PC that you are running the SALTO Software) is correctly adjusted to show the correct time, as it will determine the time on which the electronic locks operation will be based.

- To download all our locking schedule data on the portable programming device, connect the device to our computer by means of a serial cable, and go to program main menu. Click on the *PPD* icon.
- If it is the first time you use the PPD to download a locking schedule, you may be prompted with an error message

window. Click on the *YES* button to confirm that, from now on, your PPD will be exclusively devoted to your installation.

- A window like the one below will be displayed. In this window we see all doors pending initialization are selected.
- It is not compulsory to initialize all of them simultaneously, though it is highly recommended not to leave any pending door.




Figure 63

On the lower left-hand side corner we find a box called *ACTIONS TO DO*. In this box we will tick off those actions to be done with PPD.

1. If we tick off *ALLOW EMERGENCY OPENING*, this option will later be shown on the PPD menu.
2. **If we tick off *INITIALIZE LOCKS*, this option will later be shown on the PPD menu. We will now perform this action.**

To tick off these two possible options, bear in mind that it is not enough to tick off the action to do, but also to mark with a cross the door or doors on which you want to do the action.

- If we do not tick off any of these two options, the only option available in the PPD will be: Update locks.

- We can change the language of PPD display messages. In order to do that, click on the *CHANGE LANGUAGE* option.
- When we get all doors arranged in order, click on the *DOWNLOAD TO PPD* option.
- Data transfer from computer to PPD will last a few seconds. Watch the computer screen and when you see the progress bar of the active window reaches 100%, you will know the transfer is over.




Figure 64

- Now you can disconnect serial cable, and go to every door to initialize them.
- Connect to the PPD the cable connected to a special card with 3 conductors (on the opposite end you will have a RJ11 phone connector).
- Approach to the first door of your system, plug in the special cable and turn the PPD on.
- From the main menu window, select *INITIALIZE* option. You will get the door list. Now choose the door that you want to initialize. Be especially careful when performing this step, since the door name is limited.

- When you view on screen the name of the door to be initialized, click on the OK button of the PPD, and the device will request that you connect it to the lock.
- You will get on the PPD screen a *CONNECT TO LOCK* message. Insert in the lock reader the card cable and watch the PPD screen. You will get a progress bar and a sharp beep sound emitted, that means that data transfer is in progress.
- If, by mistake, this communication is interrupted for longer than three seconds, you will have to repeat the communication.
- Repeat these steps with every door within your facilities. Take into account that door names will not disappear from the door list contained in the INITIALIZE option, by having simply initialized a door. This will allow you to reinitialize a door if you have given it a wrong name.
- When you have completed the initialization process, reconnect the PPD to your computer through the serial cable, and click on CONNECT PPD icon. This will update software data comparing it with actual battery status values, as well as pending updates. At this point, INITIALIZE LOCKS menu option will not appear on your PPD main menu.

8. Advanced options

In this section some features will be described which, on some occasions are not essential, but they prove to be very important to designing the locking schedule.

General info

Go to the *TOOLS pop-up* menu and click on *GENERAL OPTIONS* option.

- The first tag we obtain, displays in the PROPERTY NAME. This is the name we gave to the data base at the start.
- We will also have more boxes, CITY and STATE/COUNTRY. Please, fill in these fields according to your facilities address.
- It is also important to fill in the FIRST DAY OF THE WEEK field, since this piece of information has an effect on calendar structure.

The screenshot shows a software window titled "Options" with a blue title bar and a close button (X) in the top right corner. Below the title bar is a menu bar with several tabs: "PMS", "Accessories", "Online", "SHIP", "Visitors", and "Advanced". Underneath the menu bar is a sub-menu bar with icons and labels: "General" (selected), "Lock", "User", "Keys", "Hotel", "PPD", and "Automatic backup". The main area of the window contains the following fields and controls:

- Property name:** A text input field containing "CMRV Controle Acces".
- City:** An empty text input field.
- State:** An empty text input field.
- First day of week:** A dropdown menu currently set to "Monday".
- Serial number:** A text input field containing "PAEXCRW-167103".
- Disable collection of personal registries on audit trail:** An unchecked checkbox.
- Select scanner:** A dropdown menu currently set to "None".
- Calibrate:** A button next to the scanner dropdown.

At the bottom of the window, there are three buttons: "Save", "Print", and "Close".

Figure 65

- The serial number field shows the serial number of the software which was written when creating the data base for the first time.
- The check box **DISABLE COLLECTION OF PERSONAL REGISTERS ON AUDIT TRAIL** can be marked if we want to filter the information kept in the audit trail , so software operators can only view the events regarding lock updates or key updates (not openings or rejections).
- The print option can be used to obtain a hardcopy report from all the tags in **OPTIONS**. It is better to use this option when the data base is completely designed, so we can see all of the fields filled out in these tags.
- Save changes before proceeding to the following tags.

PPD status

Go to the *TOOLS* pull up menu and click on the *GENERAL OPTIONS* option. On this occasion, we will choose the PPD tag.




Figure 66

- The first field refers to the length of time the downloaded data will reside in the PPDs memory. As a default value, the system sets a day, though you are allowed to increase this duration. Below, you view two optional fields, that can be selected if you want to customise the PPD default set up.
- If you tick the ENABLE EMERGENCY OPENING option, it will also be present on PPD main menu, even after data expiration.


NOTE: be careful with this option, since if you enable permanently the emergency opening option, the PPD turns into a master key that opens all your facilities doors, and could be misused if in the possession of an unauthorised person.

- If you tick COLLECT AUDIT TRAIL AUTOMATICALLY WHEN UPDATING LOCKS, the PPD will also collect the audit trails of every door, each time you update that door.
- The box COMMUNICATION PORT allows you to set which serial port you are using in the computer to communicate with the PPD.

- SALTO PA software allows you to use different com. Ports for the PPD and the encoder. You can select between using the same com. Port for both or a different com. Port for each one. The encoder com. Port is set in the EDITOR tag.

Local Options

By selecting the LOCAL OPTIONS, located in the TOOL menu, a window like the following will appear:



Picture 67

You can select to communicate with the PPD through a **USB** port. The drivers will be installed by installing the Software and any other configuration will be necessary.

On COM PORT field, you can select the PC's port through which you want to communicate with the PPD.

It is also possible to use a SERIAL port to communicate with your encoder and a different one for the PPD. By the same way, you can also use a USB port to communicate your USB encoder.

Encoder status

From the TOOLS/ LOCAL OPTIONS pop-up menu, choose EDITOR tag. A window like Picture 67 will display:

- In this window, you will view the version number of the card editor, when it is connected to your computer serial port.
- In this window, you will view the version number of the card editor, when it is connected to your computer serial port.
- This also shows the card types that are compatible with the editor if you Click on the CARDS SUPPORTED button.
- The ENABLE BEEP check box can be ticked, if you want the editor to make a noise.
- The check box SAME COM. PORT AS PPD is used to say whether we are going to use the same com. port for the PPD and encoder or whether we are going to use different com. Ports. To work with multiple com. Ports, it is necessary to have at least 2 serial com. Ports available in the computer.
- It is important to fully understand the following two key concepts to avoid confusion: the 'local serial encoder' and the 'operator's encoder'. The 'operator's encoder' refers to the actual encoder to be used by any SALTO operator that logs on locally in the SALTO software. It may be any encoder that has been setup within the system, be it serial or Ethernet. If you select Ethernet as the type of encoder,

you must also choose one among all the available Ethernet encoders.

- On the other hand, the 'local serial encoder' refers to the actual encoder connected to the machine through a serial port (or USB-to-serial adaptor). This encoder may be used by the SALTO PMS server or the SALTO SHIP server when requested to issue keys in the local encoder. Likewise, this local encoder may also be used by any SALTO operator logged on provided that the 'operator's encoder' parameter has been set to use the 'local serial encoder'.

Configuration of Ethernet encoders

To configure Ethernet encoders, the peripheral list window must be opened (*tools/peripheral list*). This window contains a list of all the peripherals set up for the installation.

Two fundamental parameters are required for each encoder: an identity number and an IP address. For the ID number, it is advisable to start from #2 since number one (#1) is normally assigned to the local serial encoder. As for the IP address, you need to obtain them from the administrator of the network. You need to make sure that the IP address is a valid one that is not already in use by any other device. IP address conflicts may lead to communication problems.

Ethernet encoder configuration can be carried out by opening the *Peripheral List* window (*Tools/Peripheral list*) as shown in the following picture;




As usual, the buttons at the bottom of the window can be used for adding, removing and editing peripheral parameters.

On the top of the window, the following buttons can be found:

- **SCAN ON/OFF:** when clicking this button, the application will check whether all peripherals in the list are connected to the machine: a green icon indicates that the corresponding peripheral is communicating whereas a red icon represents no communication.
- **SIGNAL:** this function is provided for making the LED of a particular peripheral blink and beep for a while. In this way, we can identify the location of the peripheral as well as whether the communication is OK.
- **ADDRESS:** this function is used for giving a new IP address to a peripheral. Firstly, we must press the button on the back of the encoder so that the green led starts blinking. Then, we must select a peripheral from the list and click the 'ADDRESS' button. If no error message is shown, then it is assumed that the peripheral contains the new IP address. Use 'SIGNAL' or 'SCAN ON/OFF' to check communication.

Lock status.

In this window we will specify some operating features of the electronic locks.



- You can activate the **AUDIT ALSO SHOWS DENIED ACCESS ATTEMPTS** check box if you want the Audit Trail to show failed door access attempts.
- **ALLOW LOCK ERASING:** if you enable this option, it is possible to reset any of the locks in the system. We do not recommend this option is enabled for security reasons (unless you are certain that the electronic locks may be used in more than just one locking schedule). This option can always be changed at a later date.
- **Note:** if, at a given point, you want to enable erasing of a particular lock, you will have to initialize the lock you want to reset. Updating would not be enough.
- You can tick the **ENABLE BEEP** check box if you want the electronic locks to beep on operation.
- The check box **KEYS WITH FULL AUDIT TRAIL CAN OPEN LOCKS** comes enabled by default. We can disable it if we want to make the user notice that his personal audit trail on key is full.
- **ENABLE STRICT ANTIPASSBACK**
- **CU IP ADDRESSING BY PPD.** By checking this option, the PPD will assign the IP address to the CU during the initialization. This option is very useful when the CU is part


of a network with a different range from the one where the peripheral manager is located.

- CUSVN AUTOMATIC DATE EXTENSION. This feature regulates the operation of a SVN reader when, for some reason, it is working off-line. This way, the updater will continue revalidating cards following the parameters below:
 - Days to increment: number of days to revalidate.
 - Valid refresh interval: maximum revalidation delay (in days) since last on-line update.

- If this field shows the value 00:00, then the antipass back time is unlimited, therefore the user has to go out by the exit in order to be able to enter again by the entrance.

Advanced parameters

This window is for future development. It will allow program features to be modified by the administrator. For instance, maximum number of doors which can be defined etc




It is necessary to double click the text SHOW ACCESSORIES when designing the data base for the first time if you want the ACCESSORIES tag to appear among the OPTIONS tags. If safes and energy saving devices are not going to be used in the hotel, then this step is not necessary.

If you have acquired the locks after May 2002, we recommend to set PATCH FIRMWARE = 0 in order to improve the system performance.

- **CHECK-IN START TIME:** by double clicking this sentence, it will be possible to state the start time for a guest (a time different from the edition time) . This can be interesting when we do not want the guest card working until 20:00 h, for example.
- **SVN TIMEOUT:** by double clicking this sentence, it is possible to define the time since a key is presented to the SVN control unit until the control unit receives the information from the master computer, to update that key. This time is expressed in milliseconds. This is useful for environments having long delays (slow stations, narrow bandwidth network) , anyway the majority of systems will work OK with the standard timeout delay, 2000 milliseconds. If the network is very slow, a good value would be 4000 or 6000 milliseconds.

Automatic Purge


With the option shown below it is possible to have a programmed automatic purge for the audit trail.




The purge events will be placed in a TXT file in order to be able to consult it any time it's needed.

As shown in the next pictures, there are a few options to take into account like, amount of events, % of the auditor to purge, frequency and where to keep the information.


In the next window, it's shown a window where the entire previous configuration is possible. A standard set is already done, but it is possible to modify.



Doble clic in the “Automatic Purge” row and a window like the one shown in the next picture will appear.




In the next window, it is shown how and when must be done.





Select the “Next” button and in the next window it will be indicated that there is enough information for the automatic purge.




User

The GENERAL PURPOSE FIELD FOR USERS can be enabled if we want an additional field to appear in the user detail window. This field can be used to insert some special information or number, for example, the passport number.

The check box AUTOINCREMENTAL should be marked if we want the number to increase automatically when creating a new user.

- The DEFAULT EXPIRATION PERIOD is the expiration time given to the users, by default, in the user detail window. This time is shown in days.


- The check box **DISABLE LOW BATTERY WARNING TO THE USER** can be marked if we want the locks not to give this acoustic warning , because we can be informed about this through the “on key” audit trail.
- The check box **REJECTED OPENINGS ARE ALSO INCLUDED IN THE KEY’S AUDITOR**. Can be used to obtain an “on key audit trail”, but not only for the door openings but also the denied access attempts.
- The check box **INCLUDE LAST REJECT INFORMATION ON KEYS** can be enabled if we want to know why a given key cannot open a door. You can read the last reject information by reading the key and clicking the **CONTENT** button.



Writing extra info on track 1, 2 or 3 for staff keys


To enable the space to write on the tracks first of all we have to go to the menu: **TOOLS/ CONFIGURATIONS/ GENERAL OPTIONS** and in the key tag we will see the checkboxes to enable the tracks

where we want to write in and the character size that we want to assign.
(Fig 1)




Writing extra info in users cards:


To write information in any of the tracks of the cards we have to go to the menu TOOLS/ CONFIGURATION/ GENERAL OPTIONS/ KEYS. We will find the following window (Fig. 1)



(Fig. 1)

In this window we can select the track in which we want to write, the size as well as if we want to write the info in the users keys. In addition, we have to define the the size (number of bytes) that we want to reserve for each track.


The next step will be to select what we want to write in the track. To do this we have to press the  button. We will see the following window (Fig. 2)




(Fig. 2)

In this screen we will select the macro or macros that we want to be written by default each time we encode a new key. The software allows us to write as well a constant value before or after each macro. To do this we will write it before or after the macro in the content window.

A new macro has been integrated in order to send ASCII characters such as the "ENTER"




Finally we will press the  button. As from this moment each time we issue a key this fields will be written in the selected tracks.

Show Key detect mode:

NOTE: THIS OPTION IS ONLY COMPATIBLE WITH THE FOLLOWING FIRMWARE VERSIONS. ALL PPD WITH FIRMWARE VERSIONS V.1.0.2 OR INFERIOR ARE NOT COMPATIBLE WITH THIS OPTION.


In order to activate this option in the software, we have to go to the menu: TOOLS/ CONFIGURATION/ GENERAL OPTIONS and press the “ADVANCED” tab. (Fig. 1)



(Fig. 1)

We have to pass to the advanced parameters window the option “SHOW_KEY_DETECT_MODE”

After this we will have to go to each Door, Room, iLocker and or Associated Door where we want to enable this option and enable the checkbox “ibutton key detection: Pulse mode”. (Fig. 2)




(Fig. 2)

After finishing with the selection, we will need to update all the doors, rooms, lockers or associated doors that we have modified.

Show ROM code:

In order to activate this option in the software, we have to go to the menu: TOOLS/ CONFIGURATION/ GENERAL OPTIONS and press the "ADVANCED" tab. (Fig. 1)



(Fig. 1)

We have to pass to the advanced parameters window the option “SHOW_ROM_CODE”

The ROM code will be shown when we read a key inside the content of it.

The ROM code will be shown each time we export users and each time we export the Audit Trail.


Wiegand Code:

For some external application as T&A, POS... could be interesting or necessary to send the Wiegand code of the user. In some occasions that external application needs that code to identify each of the users.

Through that tool we are going to be able to write that code on the card so can be sent to other application through the WRAdaptor, CUAdaptor or DR.

The enabling of that option has to be done on tools/general options/keys there the Wiegand option. When this is enabled on the user list can be seen the new option activated. It is important to know that the Wiegand code cannot be written directly on this field. The Wiegand code can be written on the DB through the synchronization tool. There is a column on the table to be synchronized that assign the Wiegand code to each of the users. (See Synchronization document)

When the code has been downloaded on the DB can be written on the user card and be read and sent to other application.




In the above window can be see the Wiegand code of this particular user.


FLEXIBLE WIEGAND FORMAT GENERATOR.

Keys tab in the Advanced Options allows the Wiegand cards to be encoded with different formats. This option allows the software to adapt to the Corporate 1000 format from HID or any other formats different from the classical Wiegand 26 bits format.

As can be seen in the picture below, the software will allow defining the bits composition of the Wiegand code, as well as the data format.




First of all, the different codes to consist the final Wiegand code must be set up. The New button will allow creating the different parts of the Wiegand code, as well as defining its characteristics.



The code will be internally identified with a letter, A in the example above. Any letter can be used to identify the different codes, excepting P, as this is used to identify the Parity of the codes in the beginning and end of the Wiegand code. In order to help to identify the meaning of the different codes, a short description can be included.

The digit format can be set up to Decimal or Hexadecimal, and the number of digits can be also defined. In case the code has a variable number of digits, the software will allow setting up this characteristic.

Bits can be arranged starting with the Most Significant Bit (MSB) or Less Significant Bit (LSB).



Once the codes have been created, the Interface Format will define how the codes are going to be sent and received among the different system components, defining the separators to be used among the codes.

In the example below, code A will be separated from code B using a – (dash), and B will be separated from C using a / (slash).

The table shows how the codes are going to be located, detailing where the MSB and the LSB will be located in the upper side of the table.

The Bit Composition should show how the Wiegand code is going to be arranged, starting and finishing with the Parity (P).


Parity rule 1 and 2 show how the Even (E) and Odd (O) Parities are calculated. The Xs indicate the bits that are going to be taken into account to calculate the Parity, and the dashes (-) the bits that will be ignored for this calculation.

Parity is calculated in the order shown in the lines. This is very important, because a Parity could be calculated taking into account the Parity result bit of another Parity calculation.

Port ranges

By default the PA software works on a range port from 5000 to 10000. For Network security reasons it could be interesting to delimit the range.


That's something very easy to configure on the software. On tools/Configuration/General options/Online:



On the UDP port range can be delimited it. Even if it has to be one specific port we could select it just by writing the same number on both boxes.

Auto Logoff


On the advanced parameters we can find this option as well. By means of this parameter we can adjust an automatic logout some time later that any operation is done. The time is the parameter we can adjust.



It is very simple just writing the seconds desired to be counted up before from the last operation done on the software to the Automatic Logout

Automatic Purged

On the Scheduled job list it can be found the automatic audit trail purgation. Clicking on it is pop up a wizard to configure it. The parameters which have to be set are the destination folder where we want to save the txt with the purged information, the events date we want to purge and the language in which is decided to be saved.




In this case it will be purged automatically on the Backup folder the audit trail events 5 months older.


Permanent User Deletion:

Delete permanently users that have never been used.

In order to enable the Permanent User Deletion Go to: TOOLS/CONFIGURATION/GENERAL OPTIONS and in the User lab click the "PERMANENT USERS DELETION"



Then the following screen will appear:



This window will show users that were never assigned a key. Either deleted users or not.
Select the ones you want to delete and press “delete”.

Automatic Key Assignment

Through this tool the system will be able to assign a card to the user automatically. For that, it is necessary to synchronize the ROM/UID Card code of each user to the Salto DB.

Then you can to select the key UID format depending the card it will be used (Salto, Mifare, DESfire, HIDiclass).

It is also possible to use a different code instead the Serial/ ROM code. This other code can be allocated on a specific sector in the key, specified by the key manufacturer or the card owner.

On the advanced options, User tab, you will see the window as follows. On the Mifare sector data, it is necessary to select the sector and block where the code is located.

If the sector is protected, it is necessary to place the key type and the unblocking key. It can be key A or key B.

On the Card data, it is possible to place from what byte to what byte to read the code.

In order to enable the automatic Key Assignment function Go to: TOOLS/CONFIGURATION/GENERAL OPTIONS and in the advance tab enable the ASSIGN_CARDS_AUTOMATIC


The automatic key assignment is doable by showing an empty key to an encoder or also to a WR. The encoder must be set as updater. There is no need to set a special mode on the WR, the SVN update is enough to auto assign a key.

The FW version must be the following in order to make this feature work;

Ethernet board: version **01.41** or above.


CU5000 board: version **02.02** or above.

WR: version **02.65** or above.



Then you have to select the key UID format depending the card it will be used (Salto,Mifare, DESfire, HIDiclass).

To do so, Go to TOOLS/CONFIGURATION/GENERAL OPTIONS/ USERS. On that window it can be selected the UID format:



Then on Keys/Automatic Key update (F9) the automatic key assignment is enabled and the encoder will be waiting to assign the key to the user through the UID.

More useful tools.

Key issuing

Key issuing is defined as the process of configuring a brand new carrier for later assigning/encoding in a SALTO encoder. Normally, end users are provided with carriers already issued at SALTO (such as blue, red and yellow smart cards or iButtons). These carriers can be then used in whatever property. However, certain properties require their carriers to be customized at the property according to a specific configuration. As a result, these customised carriers cannot be reused in other properties. The RW software now offers such a key issuing tool. Currently, two types of carrier are supported: PicosPass and certain smart cards. Bear in mind that issuing of certain types of carriers will require a second encoder with a special smart card.

As for the graphic interface, you need first to activate the KEY_ISSUING advanced parameter (see 'TOOL\GENERAL OPTIONS\ADVANCED') before emitting any carrier. A new tab will be shown in the general configuration window as shown in the figure below.

Within this tab you may setup all the necessary parameters required for emitting carriers in the property. In addition, a new option will also be shown within the KEYS submenu (see figure 16) to have keys emitted.




Figure 15: configuration parameters for key issuing.





Figure 16: new key issuing option.

Currently, the following types of carriers are available:

- Smart (see references)
- Picopass
- Mifare
- Desfire
- Mifare Plus 2K
- Mifare Plus 4K


Once the KEY_ISSUING=1 option is activated in General Options, a new tab will be available under the name of “Issuing”.



To work with Mifare/Desfire cards, a SAM kit must be ordered with the corresponding card and keys.

CAUTION: the modification of the following parameters must be done only under the strict supervision of a SALTO Systems technical approved technician. SALTO Systems won't be responsible for any damage caused by a bad use of this tool.

To access to the “Mifare/Desfire issuing options” press on the corresponding button.



Select the card type used in the installation:

- Mifare 1K
- Mifare 4K
- DESFire
- Mifare Plus 2K
- Mifare Plus 4K

“Custom keys” fields are used to enter the Salto SAM keys.

“Transport keys” fields are optional and may content the carrier supplier keys (customer’s keys).


MAD key is used to unblock MAD sector in case an external application need to use it.

The check box below the MAD key must be activated in case automatic selection of sectors is asked when the card has already some occupied sectors.

The READ SAM CARD button is used to capture the keys from the SAM card (the same way it is done with the SAM software).

For security reasons, the keys are hidden once the SAVE button is pressed.

DESFire Evolution 1



This version includes the possibility to work with this type of technology. With 4kbytes and 8kbytes capacities these cards use an AES128bits encryption that is much more complex and secured than the already robust 3DES.


(*) DESFire EV1 cards can be also used under a 3DES encryption.

When Desfire cards are to be used, the Diversification type can be selected in the Desfire cards set up window, as can be seen in the picture below.

Note: This option is only for specific projects developed by SALTO.

MIFARE PLUS

As can be seen in the picture above, Mifare Plus 2K and 4K cards can be selected. The “Get other sectors if unable to get selected” option is not available for the Mifare Plus cards, in comparison to the menus in the standard Mifare 1K and 4K cards.




This is a limitation given by the card, and that obliges to know the distribution of the sectors, that is to say, what sectors are free to use, so they can be assigned or set up in the software itself. The lack of the free sectors auto-detect feature must be taken into account then.

In case information from multiple sites must be encoded in the cards, bear in mind the SALTO STANDARD SAM CODES cannot be included in the sectors.

When more than a Salto site is going to use the same card, bear in mind that the at least one of the last 4 sectors of the card must be assigned to each site, being 4 the maximum number of sites to be included in the card.

The example below shows a possible sectors combination in colors. Take into account different sites might require more or less memory than the one selected in the picture, and that the selected sectors do not need to be one next to the other.



Auditor

- If you select the AUDITOR option in the pop-up menu TOOLS, a window like the following will be shown. Here, all the operations made by every operator will appear in chronological order. You can choose to view the list in order of operators, operations, etc...
- If you want to have a print out of all of this information, just press the button PRINT. Make sure a printer is on line with your computer.
- If you want to clear this window, to get more available memory space, just press the PURGE button.

Date/Time	Operator	Event	Object	Additional data
24/09/2003 13:21:21	admin	Logout		
24/09/2003 14:14:47	admin	Login		
24/09/2003 14:39:27	admin	New user	Eugenio apocio	
24/09/2003 14:40:04	admin	New user	Andrés Matinez	
24/09/2003 14:41:01	admin	New user	Cristina Fuentes	
24/09/2003 14:41:39	admin	New user	Rafael Botija	
24/09/2003 14:42:07	admin	New user	Marta de la torre	
24/09/2003 14:42:37	admin	New user	Andrés Gómez	
24/09/2003 14:43:01	admin	New user	Pedro Rubio	
24/09/2003 14:43:31	admin	New user	Enrique Zabeleta	
24/09/2003 14:44:22	admin	New user	Lucas Lopez	
24/09/2003 14:48:25	admin	Key assigned	Andrés Matinez	[24/09/2003-24/10/2004]
24/09/2003 14:48:46	admin	Key assigned	Andrés Gómez	[24/09/2003-24/10/2004]
24/09/2003 14:50:01	admin	Key assigned	Cristina Fuentes	[24/09/2003-24/10/2004]
24/09/2003 14:50:11	admin	Key assigned	Enrique Zabeleta	[24/09/2003-24/10/2004]
24/09/2003 14:50:21	admin	Key assigned	Eugenio apocio	[24/09/2003-24/10/2004]
24/09/2003 14:50:41	admin	Key assigned	Lucas Lopez	[24/09/2003-24/10/2004]
24/09/2003 14:50:51	admin	Key assigned	Marta de la torre	[24/09/2003-24/10/2004]
24/09/2003 14:50:57	admin	Key assigned	Pedro Rubio	[24/09/2003-24/10/2004]
24/09/2003 15:16:46	admin	PPD initialized	PPD	
24/09/2003 15:17:26	admin	Data download to PPD	PPD	
24/09/2003 15:52:08	admin	Logout		
25/09/2003 14:38:31	admin	Login		

On line


This tag shows the information about which computer is the communication master for online devices (On line wall readers and up daters). If we are working in a Local Area Network, with several work stations against the same data base, only one of these workstations can be the peripheral manager.


The ONLINE PERIPHERAL MANAGER field shows the name for this computer in the LAN.

The check box THIS MACHINE IS THE ON LINE PERIPHERAL MANAGER only can be ticked off for 1 workstation, should be disabled for the others workstations in the LAN.

The peripheral manager must be always running in order to permit a good synchronization with all the on-line devices.

The following warning will be shown whenever the application is going to be closed.





Peripheral menu

This menu has got 2 important options:


MONITORIZATION OF ON LINE CONTROL UNITS and PERIPHERAL LIST.

Monitoring On Line Control Units


This window will allow us to control in real time, the on line control units status and make some special operations as setting emergency open mode or emergency close mode.

One of the best advantages of the on line control unit is that the black list is transmitted automatically to this door, by pressing the UPDATE CU button (without needing to visit the door with a card just updated- carrying the black list for the cancelled user.)

This black list will be transmitted in real time if we are working with the communication master computer. If we are working with another workstation, the black list can take several minutes to be transmitted to the online control unit.




- Tick off the check box near the CU we are commanding to activate the software buttons.
- The OPEN DOOR button can be used to make a remote door opening, if the computer we are working with is the communication manager for peripherals.
- With the OPEN DOOR button we can open remotely several online control units at the same time (the ones selected).



The EMERGENCY OPEN MODE can be activated if we want the door opened for some time, no matters who is entering at this time. This has nothing to do with the standard office mode, or automatic opening. To finish this special working mode, just click the END EMERGENCY button.




After clicking the END EMERGENCY button, the door will go back to its normal operation.




The EMERGENCY CLOSED MODE can be used if we want to maintain the door closed to any user or guest (no matters they are allowed users) for some time. As we have done with the EMERGENCY

OPEN before, this EMERGENCY CLOSE MODE finishes by clicking the END EMERGENCY button.




In the image on top, we can see how 1 allowed user may enter the door. But then, after setting the EMERGENCY CLOSED MODE (3 minutes later) Pedro Rubio is no longer able to enter, because of the emergency closed mode (Image below).




- The UPDATE CU button can be used to transmit information to the control unit, when we have made a change in the data base, which implies this control unit to be updated.


- The SHOW FIRMWARE button can be used to see the firmware version for this control unit.



- A on line control unit is made from 2 elements, the Ethernet board and the CU board. Ethernet online board is shown as device 0001, Ethernet online SVN as 0002 and CU board is shown as device 0003. The firmware version for these elements has not got to be the same for both, mandatory.
- Sometimes, it may be necessary to update the firmware version, to provide the on line control unit with new features. Salto Systems will inform the customers when this operation is required. In order to download a new firmware in a on line control unit , follow these steps:
- Select the file where the new firmware file is kept, in your hard disk. You can do it by clicking the little button with 3 points at the right of the FIRMWARE FILE field.



In the example, the selected file has 2 numbers: the first means the device it is used for (Ethernet board) and the second is the version for this firmware. Now you can click the SEND FIRMWARE button to transmit the firmware file.



This operation will take several seconds. At the end of the transmission, you will get a confirmation message from the software, to assure the operation has been finished successfully.

It is possible to send the firmware file to several control units at the same time.


Then, you can repeat the procedure with the firmware for device 0003, which is the CU control board. This firmware files will be supplied by Salto when necessary.

Multiple Online Monitoring (only for Service)


When launching the monitoring window from the peripheral option, the following window will appear letting know that the monitoring module is starting the communication between the service and the software.



As you can see on the next diagram, all peripherals are on communication with the **Salto Service** and the service is the one that communicates with the data base. This way, all the Salto clients will be able to see the monitoring window even if they are not the peripheral manager.



The monitoring window allows opening, emergency open or close and end of the emergency for the selected online doors.



After lockdowns areas are created, as shown below, it is possible to emergency open and close the lockdown selected areas.



In the software for service, the monitoring window, maintenance tab, is the only place where it is possible to initialize online peripherals. It is also the only window where to update, address and do firmware updates.



Firmware update on encoders and PPDs

The new PPD unit (*) (see the picture) includes the possibility to load several firmware files at the same time. The updating procedure will be done automatically in the different devices when lower versions are detected.



(*)PPD firmware version 1.16 or higher.


Peripheral List

This list has 2 functions: creating online devices such as online wall readers and updaters, and assigning the IP address to these devices. In our example, the “main entrance” wall reader is already created, because we have created it as a door.




- The top buttons have the following functions:
- SCAN. Can be used for on line wall readers and updaters. It will inform the operator about the communication status for the online device. A green icon means good communication; a red icon means that there is some problem.

- **SIGNAL:** this button can only be used for updaters, not for on line wall readers. It makes the updater to beep and blink for a while, to locate it, if we are not sure about its physical location.
- **ADDRESS:** this button can be used for on line wall readers and up daters. After pressing the CLR button for some seconds, (while the green led is blinking) it is necessary to press the ADDRESS button, so the selected IP address will be caught by the on line device. If we do not receive an error message, it is assumed that the IP address has been properly caught by the online device.
- Always make sure that an IP address is free and available, when you are going to assign it to an online device.



We are going to create an updater in our example. This operation can only be made if we are working with the peripheral master computer, (TOOLS/OPTIONS/ON LINE).

Let's click the new button in the PERIPHERAL LIST and we can give a name to the device. Also it is necessary to write an IP address for it, and select between ETHERNET ENCODER and ON LINE CONTROL UNIT.



It is necessary to tick off the check box RUN UPDATE READER if we are creating an on line updater.

If we want the updater to beep while in operation, let's tick off the ENABLE BEEPER check box also. Then, changes must be saved and we can assign the IP address to this device.

The updater will be working continuously, and it will update any staff card which is inserted, giving it a new expiration time which is the one shown in TOOLS/OPTIONS/USER. The updater will also transmit the black list regarding the cancelled user keys. The updater does not update guest cards, it updates staff cards.



Peripheral Initialization


It is necessary to press the CLR button in the updater circuit for 4 seconds until the green LED starts blinking, and then, we must press the ADDRESS button in the software, and wait for some seconds.

It is also possible to address a CU located on a different LAN by using the PPD addressing. It is only needed to download the online doors data to the PPD and initialize the CU manually.


The PPD MUST have the FW version 01.07 or above.

Usually, when the PC sends some data to the CU, the CU answers through the same channel where the request has come. On some installation, the router used, re-route the CU's answer through another channel. In order to work with this type of router, it is possible to set a Subnet mask and a Gateway. To do so, the following is needed;

The "Set Subnet mask and Gateway IP" check box must be activated.



On the peripheral window, fill the fields with the right Subnet mask address and with the Gateway IP address. Once all this is done, it is needed to use to use the PPD to initialize the CU as told just above.



The CU and its Ethernet board must have the following version in order to work with the Subnet mask and Gateway IP;
 CU5000 board version: **02.01** or above
 Ethernet SVN board version: **01.40** or above

Inhibit Master communication


In certain properties, administrators prefer, for the sake of simplicity, centralising all the software in a unique server machine and running them remotely from workstations through a remote framework, such as Citrix or MS Terminal Server. If this is your case, you must take into account the following considerations:

In order to avoid mixing-up local configuration parameters among workstations, there should exist a separated SALTO folder per workstation within the server machine. Each of these SALTO folders should contain the same files as described in the “Installation” section, that is, the SALTO executable file, the message files (*.txt) and, most importantly, the configuration file (cnfg.ini). For example, let’s imagine that there are two workstations A and B from which remote sessions will be opened to run SALTO software within a server machine. In this case, the server machine should have got two SALTO folders (say SALTO_A and SALTO_B) containing the SALTO files as described above. Every Windows session opened from workstation A should be working with the same folder SALTO_A, whereas Windows sessions from workstation B should use folder SALTO_B.

Under Citrix or MS Terminal Server it is possible to run different SALTO instances within the same server machine (though only one SALTO instance per Windows session). This is not problematic by itself except if you have declared the server machine as being the comm. master. In this case, all the SALTO instances within the server machine will try to work in comm. Master mode, though only one of them will eventually be successful (normally, the one that was started first). If you need a particular instance to run as comm. master (no matter if it was started first or last), you must use the command line parameter ‘acm’ (Allow Comm. Master): if this parameter is set to 0, then the comm. master feature will be disabled. On the contrary, if this parameter is set to 1 (default value), the comm. master mode will be just allowed (though not necessarily enabled). Therefore, the SALTO instance that you want to work as comm. master should have got “/acm=1” in the command line and the rest of the instances “/acm=0” (see picture below).

```
C:\?RWProAccessSQL.exe /acm=0 <- This disables comm. master mode  
C:\?RWProAccessSQL.exe /acm=1 <- This allows comm. master mode
```

In summary, note that two conditions are required for a given SALTO instance to work in comm. master mode: firstly, it must be running in the machine declared as the comm. master; secondly, the ‘acm’ command line parameter, if exists, must be different from 0



Encoder and PPD firmware update

Note: This software option is exclusively limited to the E6000, E7000, EH and E9000 and just to edit cards belonging to system never used by SALTO.

The software permits you to update the key encoder.


To update the encoder's firmware you need to go to menu: TOOLS/CONFIGURATION/LOCAL OPTIONS. And click on " Show Firmware"

Next, a screen will appear (Fig.1) This screen will show you all the encoders that are available in our system.

Select the encoder or the encoders that you want to update.

Choose the root where the firmware update is located in our hard disc, clicking on the button with three points (...) located close to the firmware file field.

To transfer the update to the encoder, click on "Send Firmware"




Update the readers:

Important: Please check the reference and lot number of the escutcheon and contact Salto to see if is able to be updated. The E6000, E7000, EH and E9000 could be updated.

The software includes an option to update the readers depending on its technology and manufacturing date. To do this, we will need a special PPD which will be provided for this sort of installations.

When we will click on the PPD icon a special window to configure it the PPD will pop up.

We will need to load those files to the PPD and next, it will necessary to update the readers.




Roll-Call:

This option allows to know how many and which users are in a “Roll-Call” area in every moment. The information on “Roll-Call” areas is automatically updated every minute.

This option is enabled in the menu: TOOLS/ CONFIGURATION/ GENERAL OPTIONS/ ADVANCE/ ROLL-CALL


How to create a Roll-Call area:

In order to create a Roll-Call area we have to go to the menu: DATA/ ROLL-CALL AREA.



(Fig 2)

For each Roll-Call area we have to define the online readers that give access to that area. To do this we press the +/- button and a selection screen will appear where for each online door we can find the two readers (#1 y #2).



We have to choose which of the two readers is the entrance to the area reader and pass it to the other side in the selection window.


Note: Once we have created all the areas that we want to control we have to create one area more.

Extra Area:

This area will be the reference where we will find the users when they are not in any of the first created Roll-Call areas. In this software feature there is a very important concept: "Users do not exit an area but enter another one". If we don't create this area, the software will not be able to interpretate the exit of an area unless this exit is the entry to another area.

In order to create this area we have to select all the online WR that give exit to the previous Roll-Call areas and are not entrance to an already defined area.

Example:



In the example we have defined the different Roll-Call areas that we want to control (A1, A2, A3)

- A1: entrance readers: D2 (#1), D3 (#1)
- A2: entrance readers: D3 (#2), D4 (#1)
- A3: entrance readers: D1 (#2)

Once we have defined this Roll-Call area is necessary to create a new area A0. This area will show us How many and What Users are not in this areas (A1, A2, and A3)


A0 will have the following configuration:

- A0: entrance readers: D1(#1), D2 (#2), D4 (#2)

Monitoring of Roll-Call areas

To access to the information that the Roll-Call areas provide to us we have to go to the menu PERIPHERALS/ ROLL-CALL.

The Roll Call window will show the number of users and visitors in each of the defined Roll Call Areas, including their names and the time and date they went into that area.



(Fig. 2)

As can be seen in the picture above, if a user or visitor has to be located, it can be searched by selecting their name in the list, and clicking in the search button. The name will be highlighted, and located.

There is an option to add or remove users manually. To do this, we have to press the buttons of the bottom of the screen.

There is also a pop-up window with these options if we press the right button of the mouse.

Note: Be aware that the SALTO Roll-Call feature depends on the physical door control installation of your building. Without such hardware (i.e. turnstiles) it will be difficult to obtain a correct Roll-Call information report, as people can exit and enter in access levels without presenting their id-carriers.

Limited occupancy

This option allows creating different zones and access levels. On the access levels we can delimit the maximum number of users. So we will be able to create different access levels with different access capability.


The managing of this tool has to be done through a CU50EN or higher.

The most usual case and example for that would be a common parking where different companies would have access. For example company A could have a maximum capacity of 6 users and company B 8 users. On the software would be created 2 groups A and B with a maximum of 6 and 8 users respectively. Then when the 7 user of A

wants to entrance he will have to wait until one of those A users leaves the parking.


To configure that option we have to go Tools/General options/Advance and enable the Limited occupancy option.

Then on data we will see the limited occupancy available. The first thing that has to be done will be to create a new group:



On that window has to be created the Group name, the maximum users allowed, the users who belong to the group and the area which the group has access.

After that we can create the zone:



In the same way it has to be specified the on line door which delimits the zone and the access levels which can access to the area.

Something important to keep in mind is that all the users who belong to each of those access levels and have access to the parking need to have access to the online door which delimit the area. In this example each of the user would need access to the Parking door (online)

Going back to the example if Mike Donovan, Peter Cushing and John Mackey have already inside the parking Tony Curtis would have to wait until one of those 3 leave the area.

Language. Language change.

As default language, Salto RW software for access control has English, although you may modify it clicking on the LANGUAGES key from the front desk main menu, and choosing another amongst those in the list.

Log-out. Change operator.

When the administrator wants to make use of the access control application, he has only to click on the LOG OUT key from the front desk menu to get the login window again.




Figure 81

The administrator can then type in their password (if it was set on the TOOLS/OPERATORS AND PERMISSIONS option), and click on the OK button to enter the program with administrator privileges.

PPD connection. Portable programmer.

You may need to connect PPD to your computer in order to carry out an emergency opening, for example. This may be necessary if a door electronic lock runs out of battery.

To perform an emergency opening, follow the steps explained below. Then, click on the PPD menu option from the front desk main menu (Ensure that the PPD is connected to your computer serial port)




Figure 78

On the lower left-hand side corner we find a box called *ACTIONS TO DO*. In this box, tick off *ALLOW EMERGENCY OPENING* option. Put a cross on the door from the door list you want to open in this mode, and then, click on the *DOWNLOAD* button to transfer data on to the PPD.

- Data transfer will last a few seconds. When the progress bar reaches at 100%, disconnect the PPD from the serial cable and go to the door that requires an emergency opening.
- Turn the PPD on, clicking once on the red key, and choose *EMERGENCY OPENING* menu option. Use the scroll arrows provided to browse through the menu options.
- Click on the green key to validate your choice. PPD display will prompt you this message window: *CONNECT TO LOCK*.
- Connect PPD to the lock using a communication cable equipped with a special card on its end. Insert this card on the slot so that the conductors point towards chip side.
- You will hear the lock engine sound, and in a few seconds, the door will be ready to be opened and the PPD display will prompt you this message window: *DOOR OPEN*,


We recommend you to replace lock batteries of the newly opened door immediately. Salto locks are equipped with 3 alkaline batteries, LR03 AAA, 1, 5 V model.

After battery replacement, you must update the electronic lock with PPD, since when running out of batteries, the internal clock stops and time zones and calendars settings are lost. In order to learn how to perform a PPD update, refer to the PPD Smart User's Manual that you will find included in the RW software CD-ROM.


Audit Trail. Collecting door opening data.

It is possible to know who has opened a hotel door and at what time, by performing an audit trail on our facilities doors. To audit a door, follow the following procedure (only if it is an off line door):

- Take PPD and go to the door to be audited. Turn PPD on clicking once on the red key and browse the COLLECT OPENINGS menu option.
- Press the green key to validate the choice, and PPD will prompt you a CONNECT TO LOCK message.
- Connect PPD to lock using a communication cable which ends on a special card and you will see data transfer in progress.
- Go back to the computer and connect the PPD to the serial port.
- If you get the CONNECT TO LOCK message on PPD display, press the red key to upgrade one menu level. If you fail to do so, you will not be able to communicate with your computer.
- Click on the AUDIT TRAIL option from the front desk menu. A window like the one below will be displayed:



Now, click on the CONNECT PPD button in the application active window. The data collected with PPD will be shown in the window. SORT BY button may help you to view data according to the most convenient criterion, by date, by user, by door, etc.




Picture 79

The FILTER box allows you to view the audit trail regarding only to a particular user, door, operator ... You will have to select the user, door, operator... particular item in the field SAME AS.

In RED, are shown the denied openings, by users that don't have access to the door or guest that don't have Access to a room.

PURGE: It is highly recommended to make audit trail purges at least once a month. When the audit trail is not too full, all the communications with online units are faster and lighter, i.e. communication with Control Units, upload and download of PPD contain, and moreover, the search for audits is also faster.


For the purge, press the Purge button shown in Picture 79, and a window like the one shown below will appear.



- All events previous to the date indicated in the “Purge events before” field will be purged.
- On “File” and “Folder” fields, it is possible to select where the TXT created file will have to be kept
- If you want to turn the text in this window into a text file, just press the EXPORT button and you will be able to choose the folder to where you want to save this file.
- If you want to have all this information printed on paper, just press the PRINT button and you will have the AUDIT TRAIL printed out. Make sure a printer is connected to your computer.
- It is recommended, from time to time, to purge the AUDIT TRAIL window because the audit trail data will increasingly occupy more computer memory. In order to do this, just press the PURGE button.

New filter


To make and save special filters we have to press the “Advanced Filtering” button in the Audit Trail window. Once we press this button we will find the following window (Fig. 1)




(Fig 1)

This filter allows to filter the events by Who (user, operator and or access level) has done the event, Where (Door, Zone) it has been done. What operation or kind of operation has done and When has the operation been done.

Create a new filter


We have to select who we want to filter. To do this, we have to press the  button in the bottom of the “Who” window. We will see the following window (Fig. 2):




(Fig. 2)

We have to select the users that we want to filter, in the same way we will select the operators and access levels of users that we want to filter.

Note: If we want all the Users, Operators, Access levels to be shown we will leave in the right side of the window any user, any operator and any access level.


The next selection window is Where. This window allows us to select the Doors and Zones that we want to Filter. We will press again the  button to select the Doors and Zones that we want to filter.(Fig. 3)




(Fig 3)

In the same way we will include the Zones that we would like to filter.


Note: If we want to show the events in all Doors or Zones we will select the option “Any door” or “any zone”


The filter also permits to select the operation or access level of operations that we want to Filter. To do this we will press  button and we will select the operation or Access level of operations that we will want to filter. (Fig 4)



(Fig. 4)

Note: If we want to see all the operations that these users have made we will select “any operation”

Finally we can select the dates of our filter. To do this we will press the  button and we will see the following window (Fig 5):



(Fig. 5)

This window allows us select the filter period: selecting the last days, weeks or months or from other side select the period between 2 dates (by activating the option "Use specific period time" as well as the day or days of the week that we want to filter. (Fig. 6).

The screenshot shows a dialog box titled "Select period" with a close button in the top right corner. The dialog is divided into three main sections. The first section, "Date period", contains two radio buttons: "Last X' days" (unselected) and "Specific date period" (selected). Under "Last X' days", there is a text input field containing "0" and three radio buttons for "days", "weeks", and "months". The "Specific date period" section has "From:" and "To:" labels with dropdown menus showing "10/01/2005". The second section, "Time interval", has "From:" and "To:" labels with dropdown menus showing "00:00" and "23:59". The third section, "Day of week", has a dropdown menu showing "Any day". At the bottom are "Ok" and "Cancel" buttons.

(Fig. 6)

Once we have made all the selections we will see them in the following window (Fig 7).



(Fig. 7)


To see the results of the filters we press the



button.

The selected filter can be exported to a txt. and xls. File by pressing the export option.

Save the filter:

The software allows to save these filters for future times. To do this we have to press  button. We have to fill the name and description of the filter.


Card Template List (only for Service).

The SALTO Software allows creating different templates to print the users' cards with them. These templates can include pictures and text, and can be created by using the Card Template List option in the Tools menu, as can be seen in the picture below.



The option will run a separate application that will run over the SALTO Service, and will take the users' information from the active database.

In order to create a cards template, click on the New button and select if the design is going to be Horizontal or Vertical.



Once the orientation is selected, the rest of the options to design the card will appear, as well as the standard options related to this tool.



In the left hand column, some tools to add elements to the card template can be selected:

TEXT:

This option allows defining the typical text characteristics, like Color, Font, Location and Size.

Apart from this option, the Text can be defined to be a Constant Text, or can be a Dynamic Text.

A Constant text is a fixed text that does not change.

A Dynamic text is a text field that changes depending on the set up, and that lays on the information contained in the SALTO database.

As can be seen in the left picture below, when the Data Type is set up to Constant, the Text can be defined in the TEXT option below (highlighted in blue).

In the other hand, when the Data type is set up to Dynamic, the Data Field option is activated, and different data information belonging to the users in the installation can be included, like First Name, Last Name, User ID, External ID, Activation / Expiration Date, and General Purpose Fields. See picture on the right below.





IMAGE:


Images can be imported into the card design by using this option. As well as in the Text, images could be Constant or Dynamic.

In case Constant is selected, an image to be included in all the cards could be loaded into the template, just by clicking in the three dots button on the right of the Image option.



Pictures can be located in the Front or Back plane of the card, just by clicking with the right button over the picture, and selecting the appropriate option. Other available options are Cut, Copy, Paste or Delete.

Dynamic option allows including the picture already loaded in the User set up window, in the SALTO Software.




SHAPE:

Shapes can be also included in the card design. Rectangles and Ellipse could be added, specifying the back and line colors, as well as the width of the line.




LINE:

Lines can be added to the design, in different positions: Horizontal, Vertical, Slant and Backslant. Colors and width can also be defined, as can be seen in the pictures below.



In case the card is meant to have information in both sides, just by clicking in the Front tab with the right button of the mouse, a new tab for the Back design will appear:



Tools to be used and options for this design would be the same as for the Front side. Please check the explanations above to complete it.

Once the complete design has been done, it has to be saved.


The upper left side of the window contains the general options to manage the different card designs: New, Open, Save, Save As, Print, Grid, and Size (of the Grid).



The New option allows creating new card templates.



The Open option allows selecting any of the already created templates, so they can be modified:



The Save option allows saving the designs that are finished.



Save As options allows saving the designs with different names, in case it is necessary to sue a design base for different card designs.




Card designs can be printed into any card printer with the correct drivers related to the Pc's Operating System.



A Grid can be added to the card design at the time of designing, so there are reference lines to properly locate the different elements.

The size of this Grid could be changed, so the squares are bigger or smaller.



9. Department data base configuration

(This option is available on PA Department software or highest)

This document contains basic explanations about the 'department operator' feature. The main goal of this feature is to provide tools for managing independent departments within the same installation and for sharing common access control elements (doors, users, ...) among departments.

Some concepts must be taken in care:

Internal element: An element of the same department as the operator's.

External element: An element of another department, shared with the operator's department.

Activate departments feature

The first thing that the software administrator should do after creating the DB, is to create the departments planning, that is, decide how many departments there will be in the installation, which doors, users... will belong to each department... Once the department configuration is set up, the departments administrators are free to start working on their own department configuration as if it was an independent installation, creating their elements(users, doors, zones...) and sharing them as their own.

To make the application work on department mode, this option must be activated. So go to "Tools→ Configuration→ General options", an activate the advanced option "IS_DEPARTMENTAL" (see figure 1).




Figure 1: Advanced option to activate department feature.

How to create departments

After activating departments feature, it is possible to create new departments on “Tools→Operators and permissions→Departments”, where it is possible to see a list of existing departments, create new departments, remove departments, change departments profiles... Departments can only be created and removed by the super-admin. An administrator of a department, can make changes in his department profile, and can change elements from his department to other departments. After creating a new department, an operator group (2 if the software is PA) is created, called “DepartmentName_Administrator”, and an operator called “DepartmentName_admin” without password. (See figure 2). These operator groups and operators, can not be deleted, unless the department is deleted, by the super-admin. The administrator of each department, can also create new, modify or delete operator groups and operators for their department.

The super-admin, is also the only one allowed to allow other departments insert external doors into their internal zones.




Figure 2: Screenshot of a department profile.

There are 3 main concepts in department profile (see figure 2):

Internal elements: Here it is possible to see department internal elements, and with which department they are being shared and in which way (Modifiable or assignable).

External elements: Here it is possible to see department's external elements, that is, elements of other departments that operators of this department can modify or assign depending on the way they are shared (Modifiable or assignable).

Operations: Here it is possible to specify which operations is allowed to do the administrator of this department.

Internal elements

Here it is possible to see internal elements of the department, and which elements are being shared with which departments and in which way (Modifiable or assignable). It is possible to modify an

element's owner. An element is added to a department, every time an operator of that department creates a new one. To move an element from one department to another, go to the profile of the destination department, select the 'internal elements' tab and then click on +/- button. A new window will appear as shown in figure 3. In the right side of the screen, there are the elements belonging to current department, and in the left side of the screen, the elements of the department from which elements can be moved. So if we want to make an element belong to a department, first select the department from which the element is to be moved, and then move it with the arrows. For example, to make that User A from Dpt A belong to Dpt B, go to Dpt B profile, select internal elements and then click on +/- button. Then, in the right combo box, select Dpt A, and from the list below move User A. That will cause User A to belong to Dpt B. The super-admin, can select elements from any department, but a department administrator, can only select elements from his department.





Figure 3: Screenshot of an element department change window.

When moving elements from one department to another it is necessary to consider certain aspects: either the access rights list of the moved elements must be updated accordingly or new sharing relations must be set up for keeping department integrity. For example, consider a door A in dpt A being accessed by a user B from dpt B. If door A is moved to Dpt C, then if user A is not shared with Dpt C, or if not Door A is shared with Dpt B, User B will not be allowed to access it, so there are 2 options; remove that access or set up a relation with assignable attrib, between Door A and Dpt B. So when there is the need of moving elements from one department to another, try moving all the elements that must be moved at the same time before saving, in order not to create unnecessary relations, or not to remove needed accesses relations. The software will ask every time elements are moved between departments what to do in this case (create new relations, or remove accesses relations).

Share elements

It is possible to share users automatically between all the departments by clicking the corresponding option from “general options”.

This sharing can be defined in two different ways, Modifiable and Assignable:



- Modifiable

Both types of information, user options and user access can be modified.

- Assignable

Only the user access will be modifiable




Figure 4: Screenshot of a department shared elements window.


This option is the one that a department administrator must use to share or to remove sharing internal elements to other departments.

Caution must be taken when removing the sharing of an element with other departments since it will also imply the removal of all the external access rights. For example, consider a door A in dpt A being accessed by a user B from dpt B. If door A is not shared any longer, then user A will not be allowed to access it unless User B is shared with Dpt A.

Users automatically shared

Through this option we can share automatically all users with every department. We can find this command on general options/Department.

You will see the next window and just pushing the command automatically all users will be shared with every department.



External elements

Here it is possible to see current department's external elements, that is, elements of other departments that operators of this department can modify or assign depending on the way they are shared (Modifiable or assignable)(see figure 5). To add external elements to current department, click on +/- button, and select the external elements that want to be added or removed. To change the modifiable attrib, select the element, and click on '?' button, and select the corresponding attrib value. These operations can only be done by Super-admin, other departments administrators, can only remove external elements, but never can add external elements, neither change modifiable attrib.




Figure 5: Screenshot of a department external elements window.

Operations

Here it is possible to specify which operations is allowed to do the administrator of the department, and this department's operator groups. The way to do that, is the same as in operator groups.

Operator Groups

The way to create operator groups has not change, but there are some new issues on them (see figure 6). Permissions are now decomposed into more detailed ones, for example, now it is possible to specify if an operator can make changes in doors, users... if he can add or delete doors, users... if he can assign and cancel users keys... An operator group, can never have more permissions than his departments administrator. That is, if a department administrator has no permission for modifying doors, the operator groups of that department, will neither had permission for modifying them. Also it is possible to specify the privilege level of each operator. So if an operator group have low

privilege level, its operators would not be able to make changes in medium or high level elements, even if they have got the modify element attrib activate, neither assign them. In order to use privilege levels, it is necessary to activate it in the configuration window, in the advanced options tab.

So far, for a non departmental application, there was no restriction for downloading any door onto the PPD for initialization, updating or emergency opening.

Now with the departmental feature, such restriction exists: an operator is allowed to download only doors belonging to his department. Even the emergency opening option in the PPD is valid only for the department's doors. (Provided that the PPD firmware version is '1.01' or higher).

However, sometimes it is desirable not to have such restriction (e.g., maintenance operator group). By removing the tick in the "Manages all doors with PPD" checkbox, it is possible for an operator to download any door (even other department's doors) onto the PPD




Figure 6: Example of an operator group profile. It can be appreciated, how permissions are decomposed into more detailed ones, and how it can be specified the privilege level and the way to work with PPD.

How to work with external elements

In order to explain how to work with external elements, the explanation is going to be based on Users and zones, but this could be applied to the rest of elements of the application, that is, Access levels, doors, outputs, rooms...

When an operator accesses an element window, he can see 2 kinds of elements; internal elements and external elements that are shown in a different color (see figure 7). The operator can not delete the external elements (unless the operator is super-admin), he can modify the profile and its accesses, if it is shared with the modifiable attrib, or only change its accesses if is shared with the assignable attrib.






Figure 7: Example of a user list window. It can be appreciated external elements in a different color.

When the time comes for an operator to edit and modify a profile of a given element, he might find some restrictions due to different reasons such as: the element is external, the required privilege level is too high, the external element is not shared with the modifiable attrib, operator has no permission for performing modifications...

In order for an operator to know whether the profile can be edited or modified and to which extent, a helpful icon is shown with the following meaning:

- No padlock: The operator has most control on that user if is an internal user (he can not modify external accesses timezones if user is not shared for example), and the most control if is external (he can no change users access level, and he can not remove or add external accesses for example).

-  yellow: The operator can only change the accesses for that user, that is, add or delete operators internal doors, zones...but he can not do any change on the user profile. This occurs because the user is shared without modifiable attrib.

-  red: The operator can not do any change on the user. That occurs because the operator has not enough privilege level, or is not able to make changes to users.

To modify a user accesses, there are some consideration to take in care, depending on whether the user is internal or external.

When the user is an external one, the operator is only allowed to add/remove internal accesses only, never external ones (see figure 8). Also, the operator must have enough privilege level on that internal elements. That is, even if another department's zone has being shared to current operator's department, this zone could not be assigned to an operator's external user. And even if that zone is internal, if the operator has not enough privilege level to modify that zone, the operator is not going to be able to add/remove that zone. The elements accesses that can not be added/removed or changed, will appear with a red padlock icon.




Figure 8: Example of an external user profile. It can be appreciated external elements in a different color and the impossibility to add/remove external zones to an external user.

When the user is an internal one, the operator is allowed to add/remove any access with lower or same privilege level as the operator's, no matter if it is internal or external one (see figure 9). Has total control on internal users, with the only exception, that it is not possible to change the assigned timezone to an external access, if the external element is not shared. This case will be represented with a yellow padlock. That is, DptA.User A accesses a Dpt B.Zone B, with a Timezone, if DptA.user A is shared with DptB, then, the Timezone can not be modified, because we assume that the owner of the zone has given access to the user with the timezone he wants for that user to access his zone, but if DptB.Zone B is shared with DptA, then the timezone can be modified, because is the user owners who gives access to the zone.




Figure 9: Example of an internal user profile. It can be appreciated external elements in a different color and how can add/remove external + internal zones to an internal user.

So, to add for example an internal zone, to an external user there are 2 ways to do; Going to the profile of the external user, and adding the access to the department's internal zone, or going to the profile of the internal zone, and adding the access to the external user.

For example: To add the access DptB.UserB1 – DptA.ZoneA1, with ZoneA1 being shared to DptB, that is, ZoneA1 is DptB's external zone, there are 2 ways to do that; going to internal UserB1's profile and adding external ZoneA1, or going to external Zone A1 profile, and adding internal UserB1. And even, DptB.Operator, must have same or higher privilege level as UserB1 and ZoneA1.

In figure 8, the external accesses of an external user are shown, but these external accesses could be hidden, by going to "Tools→Configuration→General options" and in the Department window, unchecking the "Show other departments on externals elements" option. This will cause to be hidden external accesses on external elements (see figure 10).




Figure 10: Example of how to hide external accesses on external elements.

Audit trail

On audit trail window, an operator will see all the events occurred in his department's doors, and the events occurred in other department's doors caused by his department's users. This last type of events, will be shown on a different color (see figure 11).




Figure 11: Screenshot of audit trail window where it is possible to see events on internal doors, and events on externals.

Note that when an operator purge the DB, only events occurred on internal doors will be removed. So, if another department's operator purge the DB, all the events occurred on those doors caused by internal users, will be also removed.

On the system auditor, an operator will only see events caused by operators of his same department.

Programming and spare keys

Each department will only be allowed to make programming and spare keys, only for their department's rooms. The super admin can make keys for any department's room, by first selecting the department for which the key wants to be done (see figure 12).



Figure 12: Screenshot of programming and spare keys window. It can be appreciated the combo box for selecting the department the key wants to be done.

10. Automatic user data synchronisation tool

Note: This feature is only available for PA Connected or higher software.

This feature is intended for synchronising user data between two systems, SALTO's and an external one (called master), by means of text files. The master system is responsible for producing sync. data files and SALTO is responsible of processing them and alter its DB accordingly.

Basically, this feature works as follows (see the corresponding specs document for further details): the master system produces a text file containing a list of users. For each user in the list, the master must specify, among other parameters, the operation to be performed on the SALTO DB. So far, the supported operations are: 1) add a new user to the SALTO DB; 2) modify the data attributes of an existing user; 4) delete a user; 5) cancel a user's key. Therefore, unlike the IMPORT tool, which just adds new elements to the SALTO DB, the synchronisation tool is more flexible since allows users to be created, modified or deleted.

Bear in mind that the current synchronisation tool ONLY works for USERS; you cannot synchronises any other kind of entity (such as doors, time zones, etc.) In the future, the synchronisation tool MIGHT BE extended to the rest of the entities. Similarly, other types of format MIGHT BE also supported (such as Excel) in the future.

Note also that the synchronisation process is only performed by that SALTO instance declared as comm. master.

The software provides a wizard to guide the operator through the setup of a synchronisation job. Basically, within this wizard, the operator is requested to specify the type and location of sync. data files, the significance of each column within the sync. files and the time scheduling plan (see figures 9 to 13).

Effectively, sync. jobs may be scheduled according to a flexible time planning: for example, as shown in figure 13, it is possible to execute a sync. job on a regular basis (every ten minutes in every day). Thanks to this flexible time scheduling, master systems may synchronise their user data in an automatic way without any manual intervention in the SALTO software.

Please refer to the corresponding specs document to learn the user data model on which the synchronisation tool is based. Not every user data is synchronisable: for example, in this current version, it is not allowed to synchronise data concerning access permissions (doors/zones and timezones).

As for the graphic interface, you may create a user synchronisation job in two different ways, as seen in the pictures below: either by selecting the 'FILE\IMPORT/EXPORT\SYNCHRONISATION' menu option or the 'TOOLS\SCHEDULED JOBS' one. Whichever option you choose, you end up with a new sync job added to the list of scheduled jobs, as seen in figure 8. You may modify the settings of an

already scheduled sync job at any time by clicking on the 'View details' button in the job list window. By doing so, the same wizard will be launched again for you to perform the desired changes.





Figure 7: two different options for executing a synchronisation job.



Figure 8: list of scheduled jobs.




Figure 9: data sync wizard. Specifying the type and location of data.

The Data source type can be selected, depending of the type of file to be used in the Synchronization task. The file could be a CSV file (*.csv, *.txt files) or a Database Table (DB Table, like SQL Server, Oracle or ODBC Data sources tables). This last option is only for Pro Access For Service.

Please refer to the following documents to have more details about the data synchronization for:

CSV files: SALTO_Data_Sync_1_9 document.

DB Tables: SALTO_User_Sync_Staging_Table_0_9 document.




Figure 10: data sync wizard. Specifying the CSV parameters and type of entity.




Figure 11: data sync wizard. Specifying the significance of columns within the CSV file.




Figure 12: data sync wizard. Specifying the time scheduling plan and name of the job. It is possible to program synchronization every 1 second.





Figure 13: data sync wizard. Specifying the time scheduling planning.

11. SALTO Host Interface Protocol SHIP

Important: This option only is available on PA Department SHIP and PA Department SHIP

In order to activate the SHIP feature we have to go to the menu **TOOLS/CONFIGURATION/GENERAL OPTIONS** and press the SHIP tab. We will find the following window (Fig. 1).



(Fig. 1)

Activate communication SALTO (server) – Host (client)

When SALTO acts like server first of all we have to activate the following checkbox : Enable SHIP server in this machine

Once we have activated it we will see the name of the PC that is going to work as Server “SALTO server (Ship)

Finally we have to select the TCP/IP port from where the communication is going to be made.

The option will allow us to view all the information shared between the SALTO server and all the clients connected.

Activate communication SALTO (client) – Host (Server)

When the HOST is the server we have to enable the following checkbox:



Once enabled we have to fill up the “HOST server (ship)” with the name or IP address of the PC that is going to make this function.

After that we have to fill up the number of connections that we are going to establish and the TCP/IP port where the communications are going to be made.

The “Timeout” is the time that a client SALTO waits for the server HOST to answer a request and return a result.

The option  will allow us to view all the information shared between the SALTO server and all the clients connected.

12. SALTO Wireless



System setup

Together with the offline locks the system can be improved with the use of the Salto Wireless escutcheons. This section describes the steps to setup a complete Wireless installation.

12.1 RF_ENABLED=1

To start setting up the Wireless system, the radio frequency (RF) module must be activated.

Follow the next steps:




12.2 RF OPTIONS

Under RF OPTIONS the general parameters of the system are defined.

Follow the next steps:



Site scan channels



The SALTO Wireless system uses the IEEE 802.15.4 protocol transmitting the signal at a high frequency range of 2,4GHz. This window shows the 16 different channels showing the name (in hexadecimal) and the corresponding frequency.

In order to improve the quality of the transmissions, a channels filter is suitable. Contact with your SALTO dealer for more details.

Lock params

. Self healing start time


This parameter (in units of 30min) defines the time the system will wait to start with the Self healing process.

The Self healing process is started by the Wireless lock to look for a new parent device (Gateway or Repeater) when the communication has been lost.

. Lock heartbeat period

This parameter (in units of 10s) defines the frequency of the lock's heartbeat. It consists in a brief signal the lock emits to be seen by its parent device (Gateway or Repeater)



Note: If there is no parent device redundancy, it is recommended to use “0” to disable the self healing process.



12.3 Gateways


The different Gateways must be declared with their static IP address.

Follow the next steps:




Once the Gateway is declared it must be addressed to establish the communication.

Follow the next steps:



The CLR button must be pressed to put the Gateway in address mode. Then the Address button must be used.


By clicking on the “Scan on” button the “com.” led will show the status of the Gateway.



12.4 Repeaters

The Repeaters are managed through a separate window.

Follow the next steps:



2 parameters define this device:

- RF MAC address

This parameter consists of 3 pairs of hexadecimal numbers and is printed on the Repeater RF antennae.


- Parent device

The Repeater has to be associated to another Gateway or Repeater (its parent device).



Note: the Gateway does not have any MAC address.


Once everything is setup, the Repeaters will associate themselves to their parent device establishing the communication.



12.5 Wireless locks


The wireless locks are created through the DOORS menu.

Follow the next steps:



Mark the RF option in order to make it Wireless.

Once the different doors are created they have to be initialized with the PPD. The escutcheons start the process to look for the available static devices (Gateways / Repeaters) and associate to them.



Monitoring of online locks

The online wireless system can be monitor through this window.


Follow the next steps:

Peripherals
Monitoring of online locks


Two new tabs give information about the status of the wireless escutcheons.

RF locks



This window allows monitoring the status of the wireless locks. Together with the door name, parameters like the coverage (level of signal), the battery status, door left open and intrusion signals are displayed.



While the bottom part shows the events in real time, on the right hand side the following options are available:




It allows a remote timed opening of the selected wireless locks (the opening delay is based on the “Increased open time”).




The selected locks can be opened remotely (and stay opened). Prior to use this option, the lock must have the office mode enabled.



An online update can be performed in order to send the last hardware modifications.



Whenever a user is cancelled the black list is periodically sent to the online devices (CU + wireless locks). This option permits to force a manual sending of this information.



This option sends a test signal that returns a “beep” from the escutcheon confirming the communication.


Read version

The wireless lock firmware version will be displayed:

- RF antennae
- Control
- Reader

RF Network


The different wireless locks will associate automatically to the best possibility of parent device (Gateway / Repeater) in terms of availability and signal level.



Lockdown

This option allows securing a defined area with CU and Wireless locks in order to easily close all the accesses in an emergency situation.


An activation of this feature is needed in the “Advanced” tab of the “General Options”: LOCKDOWN_ENABLED=1



Follow the next steps:

**Data
Lockdown areas**


The lockdown area will group a list of online wall readers together with wireless locks.



Follow the next steps:

**Peripheral
Lockdown**

Once the areas are defined the “Emergency close” button can be used to remotely close all (or the selected) the doors within an area or “Emergency Open” if necessary.



The access to these units will be denied (even if the user has the rights on the card) until “End emergency” button is pressed. Only the authorized users with the “Override lockdown” options will be able to open them.

